



MANUAL & PNEUMATIC OIL EXTRACTOR

77057 - INSTRUCTIONS FOR USE

1. Product Introduction

Read this leaflet in full before using this product and retain it for future use.
Please visit [drapertools.com/manuals](https://www.drapertools.com/manuals) for the latest version.

1.1 Intended Use

This product is designed to extract oils and brake fluids from motor vehicles, motor bikes, marine engines, gearboxes, generators etc. without the removal of the oil drain plug. Easily operated by using either hand pump action or with a compressed air supply.

Any other application beyond the conditions established for use will be considered misuse. Draper Tools accepts no responsibility for improper use of this product.

2. Specification

Stock No.	77057
Part No.	OE2
Reservoir capacity:	10L
Air Inlet size:	1/4" BSP
Pressure rating:	0.8MPa

3. Health and Safety Information

Important: Read all the Health and Safety instructions before attempting to operate, maintain or repair this product. Failure to follow these instructions may result in injury or damage to the user, the product or the vehicle.

- **WARNING!** Used engine oil is carcinogenic – always wear protective gloves.
- **DO NOT** allow waste fluid types to mix in the reservoir.
- At the end of its working life, dispose of the product responsibly and in line with local regulations. Recycle where possible.
- Dispose of oil separately and in accordance with local regulations; **DO NOT** abandon it in the environment.
- **WARNING!** Keep packaging materials out of reach of children. Dispose of packaging correctly and responsibly and in accordance with local regulations.

4. Identification - Fig. 1



Fig. 1

- 1.5m Suction tube
- Exhaust
- Air inlet
- Air control valve
- Reservoir cap
- Manual pump handle

Extraction Tubes

- 1 x 6mm O.D. x 4mm I.D. blue plastic coated metal
- 1 x 6mm O.D. translucent plastic
- 1 x 9mm O.D. clear plastic

5. Operation and use

- Before use check that the vehicle is suitable for use with vacuum extraction – refer to the manufacturer's or Haynes workshop manual.

5.1 Manual Operation

1. Fit the most suitable extraction tube (A), (B) or (C) to the suction tube (1).
2. Pump the handle (6) up and down to create the suction vacuum.
3. Open the air control valve (4) to extract the fluid and close to stop extraction.

5.2 Using Compressed Air

1. Check that the air pressure is set correctly and that the control valve (4) is fully closed before connecting to the air supply.
2. Fit the most suitable extraction tube (A), (B) or (C) to the suction tube (1).
3. Open the air control valve (4) to extract the fluid and close to stop extraction.

5.3 Emptying The Reservoir

1. Close the air control valve and disconnect from the air supply.
2. Remove the reservoir cap (5) and pour into a suitable storage/transport container.

6. Warranty

6 Months - Visit [drapertools.com/warranty](https://www.drapertools.com/warranty) for full details.

Please visit [drapertools.com/manuals](https://www.drapertools.com/manuals) for the latest version of this manual and the associated parts list, if applicable.