

To make assembly easier we recommend having two persons aid one another in assembly.

1. Unpack

Unpack your worktop and check that it was not damaged during transit and all the parts are included.

2. Attach Worktop

Place the worktop onto the trolley. Align the pre-drilled holes in the brackets with the holes in the trolley and side handle. Secure with the 8 X M6 (12mm) Bolts and 8 X M6 Nuts supplied.

