



AIR CONDITIONER UNIT WINDOW KIT 24221

Product Reference

User Manual for: Air Conditioner Unit Window Kit

Fits Stock Nos. 23828, 23830 & 23833

Suitable for side, top and bottom hinged windows.

Stock No: 24221

Part No: WK1

Version 1: December 2023

First release

As our manuals are continually updated, always ensure that the latest version is used.

Please visit drapertools.com/manuals for the latest version of this manual and the associated parts list, if applicable.

Copyright © Notice

Copyright © Draper Tools Limited.

Contents

- Self adhesive hook tape.
- 4 metres of window seal.

Instructions for use

1. Measure the total distance around the window – total must not exceed 4 metres (**fig.1**).
2. Clean and dry the frames before trying to apply the adhesive tape.



FIG.1

3. Apply the tape to the window and frame – **see fig. 2** for correct position.
4. Fit the fabric to the inner frame with zip closest to the opening window, then fit the fabric to the opening window. Do not try and cut to size, use the remaining adhesive tap to secure any overlap.
Note: a complete seal will not be achieved.
5. Open the zip at the bottom corner of the window opening (A), far enough to fit the exhaust hose and connector through. Zip up to secure and complete venting to the outside.



FIG.2

EN

Original Instructions
Version 1 – January 2024