

# TRANSFER PUMP

#### 01082

Read this manual in full before using this product and retain it for future use. Always use the latest version of the manual; visit **drapertools.com/manuals** for the latest release.

#### 1. Health and Safety Instructions

- Keep hands clear of moving parts when the pump is in use.
- ALWAYS read and adhere to any safety information provided with any liquids to be transferred.
- DO NOT pump flammable liquids near sparks or open flames or allow them to splash onto hot surfaces.
- Clean the pump thoroughly after every use to prevent contamination.
- DO NOT over-inflate items with air.
- Wear appropriate PPE for the task to be performed.
- This product is **NOT** suitable for potable (consumable by humans) fluid applications. (A) 2. What's in the Box? (E) 1 x Pump Α. INTAKE (F) В. 2 x Ø 12mm X 1.300mm fluid transfer hoses 1 x 400mm black air pressure hose 1 x Lock-on connector D. E. 1 x Needle valve adaptor F. 1 x Plastic valve adaptor (D) (C) **OUTLET** (B)-

### 3. Siphon or Transfer of Fluids

- Press and hold the upper INTAKE port connector inwards and insert a clear hose, then release the connector to lock it in place.
- 2. Attach the other clear hose to the OUTLET port in the same way.
- 3. Insert the INTAKE hose into the fluid to be transferred and the OUTLET hose into the destination reservoir. **Important:** When siphoning fluid, the discharge point must be lower than the INTAKE hose.
- 4. Pump the handle several times until the fluid begins to flow, then leave the handle in the open position; the flow should continue automatically but can be accelerated by continued pumping.
- 5. To remove the hoses, press and hold the port connectors and detach the hoses from the ports.

#### 4. Use as an Air Pump

- 1. Insert the serrated nozzle of the lock-on connector into the end of the black hose with the metal ring.
- 2. Press and hold the lower OUTLET port connector inwards and insert the bare end of the black hose, then release the connector to lock it in place.
- 3. Insert the appropriate adaptor squarely into the lock-on connector and fold down the lever to secure it.
- 4. Insert the adaptor into the valve of the inflatable and pump the handle to inflate.

#### 5. Product Care and Disposal

- Flush the pump and the clear hoses with warm, clean water after every use.
- Clean the pump body with a damp cloth only; **DO NOT** use solvents or aggressive chemicals.
- Clear up spillages immediately and appropriately.
- If the pump lubricant begins to dry out, lift the handle to its highest position and spray a few drops of light oil into the INTAKE port, then pump the handle several times.
  Important: DO NOT use penetrating oil.
- Store this product in a clean and dry environment, out of direct sunlight and out of reach of children.
- · Dispose of waste fluids separately and in accordance with local regulations; ALWAYS read the label.
- Dispose of this product responsibly and in accordance with local regulations; recycle where possible.

## 6. Symbols



Read the instruction manual



Fluid hose length



Air hose length



Suitable for use with antifreeze



Suitable for use with petrol



Suitable for use with diesel

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355 Website: drapertools.com Email: sales@drapertools.com