

DRAPER

EXPERT

EN













Original Instructions
Version 1 – 09/24






24W HYBRID

AC/DC WORK LIGHT

04673







Health and Safety Information

EN

Important: Read all the Health and Safety instructions before operating or maintaining this product and retain for later use. Failure to read these instructions may result in injury or damage to the user or the product.

- **DO NOT** shine the light directly into eyes.
- **DO NOT** allow children to use the light.
- **DO NOT** use the light near water sources or expose to rain.
- **DO NOT** operate near any heat sources such as radiators, stoves or other equipment that produces heat.



WARNING! To reduce the risk of burns or fire:

- Only use the AC adaptor supplied or an approved compatible battery pack to operate this light.
- **DO NOT** attempt to open, disassemble, modify or service the light.
- **DO NOT** crush, puncture, short external contacts or dispose of in fire or water.
- **DO NOT** use this product if the light, adaptor or battery pack are damaged in any way.

Connection to the Power Supply

This light/adaptor is Class II* (double insulated) and is designed for connection to a power supply matching that detailed on the rating label and compatible with the plug fitted.

*Double Insulated (□): This product is double insulated and does not require an earth connection to protect against electric shock from accessible conductive parts in the event of failure of the basic insulation.

AC Adaptor

- For indoor use only. **DO NOT** expose to rain.
- Before plugging in, check the adaptor casing, cord and plug are in good condition. If damaged in any way have it checked by a qualified person before next use.
- Set up the adaptor and cord in a safe place where it cannot be knocked, tripped over or stepped on.
- If the adaptor or cord are damaged replace only with one recommended by Draper Tools.

Battery Pack & Charger

- Before using the battery pack, read all instructions and cautionary markings on the battery charger, battery and product using the battery.
- Recharge only with the charger specified by the battery pack manufacturer.
- Only use chargers and battery packs that are recommended by Draper for use with this light.

- For indoor use only. **DO NOT** expose to rain.
- Disconnect the charger from the power supply before removing or fitting the battery.
- **DO NOT** leave battery in a discharged state, recharge battery immediately.

Product Overview

EN

- 1 LED SMD Light
- 2 Stand adjuster
- 3 USB output 5V/1A
- 4 ON/OFF/Brightness button
- 5 1 × 07069 Battery adaptor
- 6 Foldable stand
- 7 Hanging hook
- 8 4 × Base magnets
- 9 AC adaptor input port
- 10 Input AC adaptor (100 – 240V)

Optional Accessories (not supplied)

- 07069 – 1 × DeWalt/Milwaukee battery adaptor
- 07070 – 1 × Makita battery adaptor
- 07071 – 1 × Bosch battery adaptor
- 07072 – 1 × Black & Decker /Stanley battery adaptor
- 07075 - 1 × Input AC adaptor

Please visit [drapertools.com](https://www.drapertools.com) for our full range of accessories and consumables.

Set Up and Operation

EN

Using AC Mains Power

B – D

- Always unplug from the power supply after use.

Using DC 18V/2.0Ah Power Tool Battery Pack (not supplied)

E – H

1. Fit the battery adaptor and slide on a compatible 18V/2.0Ah Li-ion battery pack (as marked on the adaptor).
 - Ensure the battery pack is fully charged before fitting to the light. If it requires charging, remove from the light and follow the instructions supplied with the battery pack and compatible charger.

- Battery life will depend on battery condition and type used.

2. Always switch the light off after use.

Operating the Light

I – L

Adjusting the Stand

M

USB Power Outlet

N – O

Maintenance and Storage

P – R

Remove the battery pack from the light when not in use and when storing for prolong periods.

Warranty

S

Warranty period is 12 months from date of purchase.

Visit [drapertools.com/warranty/](https://www.drapertools.com/warranty/) for more information.

At the end of its working life, dispose of the product responsibly and in line with local regulations. Recycle where possible.

Contact Details

Draper Tools

Draper Tools Limited
Hursley Road
Chandler's Ford
Eastleigh
SO53 1YF
UK

Delta International

Delta International BV
Oude Graaf 8
002 NL
Weert
Netherlands

Website: [drapertools.com](https://www.drapertools.com)

Email: sales@drapertools.com

Product Helpline: +44 (0) 23 8049 4344

Telephone Sales Desk: +44 (0) 23 8049 4333

General Enquiries: +44 (0) 23 8026 6355

Please contact the Draper Tools Product Helpline for repair and servicing enquiries.

© Published by Draper Tools Limited