



# MOTORCYCLE SCISSOR STAND

04991



These instructions accompanying the product are the original instructions. This document is part of the product, keep it for the life of the product, passing it on to any subsequent holder of the product. Read all these instructions before assembling, operating or maintaining this product.

This manual has been compiled by Draper Tools describing the purpose for which the product has been designed, and contains all the necessary information to ensure its correct and safe use. Following all the general safety instructions contained in this manual will ensure both product and operator safety, together with longer life of the product itself.

All photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the product.

While every effort has been made to ensure the accuracy of information contained in this manual, the Draper Tools policy of continuous improvement determines the right to make modifications without prior warning.

### 1. TITLE PAGE

#### 1.1 INTRODUCTION:

USER MANUAL FOR: Motorcycle Scissor Stand Stock No: 04991. Part No: MCPL1.

#### 1.2 REVISIONS:

Date first published August 2011.

Date of revision November 2021.

As our user manuals are continually updated, users should make sure that they use the very latest version.

Downloads are available from: drapertools.com/manuals

Draper Tools Limited Hursley Road Chandler's Ford Eastleigh Hampshire SO53 1YF UK Draper Tools Limited Oude Graaf 8 6002 NL WEERT Netherlands

Website: drapertools.com Product Help Line: +44 (0) 23 8049 4344 General Fax: +44 (0) 23 8026 0784

#### 1.3 UNDERSTANDING THIS MANUAL'S SAFETY CONTENT:

Warning! – Information that draws attention to the risk of injury or death. Important – Information that draws attention to the risk of damage to the product or surroundings.

#### 1.4 COPYRIGHT © NOTICE:

Copyright © Draper Tools Limited.

Permission is granted to reproduce this publication for personal and educational use only. Commercial copying, redistribution, hiring or lending is prohibited.

No part of this publication may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited.

In all cases this copyright notice must remain intact.

### 2.1 TABLE OF CONTENTS

1.	TITLE PAGE			
	1.1	INTRODUCTION		
	1.2		2	
	1.3 1.4	UNDERSTANDING THIS MANUAL'S SAFETY CONTENT COPYRIGHT © NOTICE		
			2	
2.	CONTE		_	
	2.1	TABLE OF CONTENTS	3	
3.	WARRANTY			
	3.1	WARRANTY	4	
4.	INTRODUCTION			
	4.1	SCOPE	5	
	4.2	SPECIFICATION		
	4.3	HANDLING AND STORAGE	5	
5.	HEALTH AND SAFETY INFORMATION			
	5.1	GENERAL SAFETY INSTRUCTIONS		
	5.2	RESIDUAL RISK	6	
6.	TECHNICAL DESCRIPTION			
	6.1	IDENTIFICATION	7	
7.	UNPACKING AND CHECKING			
	7.1	PACKAGING	8	
8	OPERATING INSTRUCTIONS			
0.	81	OPERATION AND USE	9	
9.	MAINT		č	
9.	9.1	MAINTENANCE	10	
			U	
10.	DISPOSAL			
	10.1	DISPOSAL	1	
11.	EXPLANATION OF SYMBOLS			
	11.1	EXPLANATION OF SYMBOLS 1	2	

### 3. WARRANTY

#### 3.1 WARRANTY

Draper tools have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship.

Should the tool develop a fault, please return the complete tool to your nearest distributor or contact:

#### Draper Tools Limited, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF, England. Telephone Sales Desk: +44 (0) 23 8049 4333 or Product Help Line +44 (0) 23 8049 4344. A proof of purchase **must** be provided with the tool.

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This warranty period covering parts and labour is 12 months from the date of purchase, except where tools are hired out when the warranty period is 90 days from the date of purchase. This warranty does not apply to any consumable parts, any type of battery or normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted or made by any personnel other than the authorised Draper warranty repair agent.

Note: If the tool is found not to be within the terms of warranty, repairs and carriage charges will be quoted and made accordingly.

This warranty applies in lieu of any other warranty expressed or implied and variations of its terms are not authorised.

Your Draper warranty is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the warranty period.

Please note that this warranty is an additional benefit and does not affect your statutory rights. **Draper Tools Limited.** 

# 4. INTRODUCTION

#### 4.1 SCOPE

Motorcycle Scissor Stand stand suitable for use on the floor or on a motorcycle lift.

#### 4.2 SPECIFICATION

Stock No.	04991
Part No.	MCPL1
Capacity	450kg
Safe Working Load	450kg
Minimum Height	
Maximum Height	
Platform Size	
Base Size	
Nett Weight	
-	•

#### 4.3 HANDLING AND STORAGE

- Care must be taken when handling this product.
  - · This product is not a toy and must be respected.
- Environmental conditions can have a detrimental effect on this product if neglected.
  - · Exposure to damp air can gradually corrode components.
  - · If not cleaned and maintained correctly or regularly, the machine will not perform at its best.

### 5. HEALTH AND SAFETY INFORMATION

#### 5.1 GENERAL SAFETY INSTRUCTIONS


- Warning! Before use, ensure that the motorcycle to be supported has a suitable structure and centre of gravity to accommodate the platform without damaging the motorcycle. Do not use if the stand will foul on the exhaust or other vulnerable parts.
- Place the stand in a suitable work area. Keep the area clean and tidy and free from unrelated
  materials and ensure that there is adequate lighting. Ensure that the floor is level and strong
  enough (preferably concrete) to take the weight of the stand and the bike. Do not operate the
  stand on tarmacadam as the surface may be unstable.
- Keep the stand clean for best and safest performance.
- The maximum bike weight is 450kg. Do not exceed this rated capacity.
- Before lifting, check that there are no overhead obstructions.
- Keep children and unauthorised persons away from the work area.
- Do not use the stand for a task it is not designed to perform.
- Do not operate the stand if damaged.
- Do not exceed the rated capacity of the stand.
- Do not allow untrained persons to operate the stand.
- Do not make any modifications to the stand.
- Before lowering the stand, ensure that there are no obstructions underneath the motorcycle and that all persons are standing clear.
- Before storing, ensure that all parts are clean and free of grease and oil and the stand is fully lowered. Store stand in a safe area.
- Warning! The instructions referred to in this manual are unable to cover all possible situations that may occur. It must be understood that common sense and caution are factors which are unable to build into this product, but must be applied by the operator.

#### 5.2 RESIDUAL RISK

Important: Although the safety instructions and operating manuals for our tools contain extensive instructions for safe working with lifting equipment, every machine involves a certain residual risk which can not be completely excluded by safety mechanisms. Lifting equipment must therefore always be operated with caution!

### 6. TECHNICAL DESCRIPTION

### 6.1 IDENTIFICATION





Base foot.

# 7. UNPACKING AND CHECKING

#### 7.1 PACKAGING

Carefully remove the product from the packaging and examine it for any sign of damage that may have happened during shipping. Lay the contents out and check them against the parts shown on page 7. If any part is damaged or missing, please contact the Draper Help Line (the telephone number appears on the Title page) and do not attempt to use the product.

The packaging material should be retained at least during the warranty period, in case the machine needs to be returned for repair.

#### Warning!

- Some of the packaging materials used may be harmful to children. Do not leave any of these
  materials in the reach of children.
- If any of the packaging is to be thrown away, make sure it is disposed of correctly, according to local regulations.

# 8. OPERATING INSTRUCTIONS

#### 8.1 OPERATION AND USE

- Warning! Before use, ensure you read, understand and apply the safety instructions.
- Warning! Before use, ensure that the motorcycle has a suitable structure and centre of gravity to accommodate the stand, without damaging the bike.
- Do not use the stand if it will foul on the exhaust, fairing or other vulnerable parts. If necessary, remove any lower fairing and ensure that the bike is stable on the stand before operating.
- Position the bike in a suitable area, checking that the surface on which the stand will be placed
  is solid and flat (preferably concrete).
- Ensure there is good access and clearance beneath the bike for the stand.
- The stand can be also be used in conjunction with a motorcycle that is already raised on a
  motorcycle lift. Ensure that the stand is centrally located, secure and stable on the lift platform.
- Inspect the underside of the motorcycle for suitable support points, bearing in mind the centre
  of gravity of the motorcycle and which wheel is to be lifted from the ground.
- Place the stand under the motorcycle in the approximate position required.
- Turn the hexagonal shaft clockwise to raise the stand until the platform is in contact with the underside of the motorcycle. Adjust the position of the stand as necessary and proceed to raise the bike.
  - For additional security, it is advisable to secure the motorcycle on the stand with suitable straps, especially if the motorcycle is already raised from the ground on a motorcycle lift.
- When work is complete, check under the stand to ensure that there are no obstructions and that it is safe to lower the unit.
- When the stand is fully lowered, ensure that the bike is standing on its wheels and is supported in the upright position.

### 9. MAINTENANCE

### 9.1 MAINTENANCE

- When the stand is not in use, store it in the lowered position.
- Keep the stand clean and wipe off any oil or grease. Lubricate all moving parts with oil.
- Check all parts before use. If any part of the stand is damaged or defective, remove the stand from service and take the necessary action to remedy the problem.
- Do not use the stand if it is believed to have been subjected to abnormal load or shock. Inspect
  and take appropriate action.

#### 10.1 DISPOSAL

- At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.
- Contact your local authority for details of collection schemes in your area. In all circumstances:
  - · Do not dispose of power tools with domestic waste.
  - · Do not incinerate.
  - · Do not abandon in the environment.

# 11. EXPLANATION OF SYMBOLS

### 11.1 EXPLANATION OF SYMBOLS



Read the instruction manual.



Do not abandon in the environment.



Keep out of the reach of children.



Maximum safe working load.



Minimum and maximum lifting height range.



Base dimensions



Platform dimensions



Net product weight (example shown).



Warning!

European safety standards conformity.



European conformity.

### CONTACTS

Draper Tools Limited, Hursley Road, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF, U.K.

EU: Oude Graaf 8 6002 NL Weert (NL)

Help Line: +44 (0) 23 8049 4344

Sales Desk: +44 (0) 23 8049 4333

Internet: drapertools.com

Email: sales@drapertools.com

General Enquiries: +44 (0) 23 8026 6355

Service/Warranty Repair Agent:

For aftersales servicing or warranty repairs, please contact the Draper Tools Help Line for details of an agent in your local area.

YOUR DRAPER STOCKIST

MSPR1221

©Published by Draper Tools Limited.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical photocopying, recording or otherwise without prior permission in writing from Draper Tools Ltd.