



**EN**

Original Instructions  
Version 2 – November 2024

# FLEXIBLE NOZZLE UNDERBODY **COATING GUN**

**15875**



# 1. Introduction

User Manual for: Flexible Nozzle Underbody Coating Gun

Stock No: 15875

Part No: DAT-UCG

## 1.1 Revisions

Version 1: April 2021

First release

Version 2: November 2024

# 2. Intended Use

This underbody gun is designed to be used to rustproof vehicle chassis and is suitable for use with various primers and sub coat paints. It is suitable for use with most types of 1 litre coating tins. It is supplied with a 1/4" BSP connector and 500mm flexible nozzle for accurate spraying and for fitting into confined spaces such as wheel arches.

Any other application beyond the conditions established for use will be considered misuse. Draper Tools accepts no responsibility for improper use of this product.

# 3. Specification

Stock No.	15875
Part No.	DAT-UCG
Air inlet	1/4" BSP
Air Pressure	
Rated	30 – 100psi
Maximum	116psi
Air Consumption	270L/min
Recommended Air Pressure	2 – 7bars
Net Weight	340g

# 4. Health and Safety Information

**Important:** Read all the Health and Safety instructions before attempting to operate, maintain or repair this product. Failure to follow these instructions may result in injury or damage to the user, the product or the workplace.

## 4.1 General Health and Safety Precautions

- Only authorised personnel who have carefully read and understood this manual may operate, adjust and repair this product.
- Observe all standard safety precautions and good practices when working with air tools.
  - Always wear adequate eye protection and a face mask when using this product. Some products suitable for use with this product may contain chemicals or toxic components. Avoid inhalation or contact with materials used with this product. If contact occurs, seek medical advice as soon as possible.
  - Wear protective gloves while using this product.
- Keep your work environment clear and well-lit, with bystanders at a safe distance.
- Use this product **ONLY** in well-ventilated areas to avoid the build-up of fumes and allow paint particles to disperse.
- Keep out of reach of children.
- Before every use, inspect the coating gun for missing, broken, loose or corroded parts.

**Important: DO NOT** use this product if it is damaged in any way. Contact Draper Tools to discuss repair and replacement options.
- Ensure that all accessories and attachments are securely tightened before use.
- Use the product only in the manner instructed in this manual.
- **DO NOT** modify this product in any way.
- **ONLY** use spare parts supplied by Draper Tools.
- Stay alert at all times; **DO NOT** use this product while tired or under the influence of alcohol, drugs or other medication

## 4.2 Additional Safety Instructions for Air Tools

- Compressed air can cause severe injury. **ALWAYS** turn off and disconnect the air supply before making any adjustments to the product or leaving it unattended.
- **NEVER** direct this product towards yourself or others.
- Ensure that compressed air is not blocked by or in contact with any part of your body.
- **ONLY** use clean, dry and regulated compressed air.




**WARNING! NEVER** use oxygen, combustible gases or other bottled gases as a supply for this product. Use of these substances may cause the product to explode.

- **ALWAYS** check for and replace damaged or loose hoses and fittings.
- Ensure that the product is compatible with the air supply before use.
- Ensure all connections are securely tightened.
- **DO NOT** exceed the maximum stated air pressure.
- **DO NOT** obstruct the ability of the trigger to release once depressed.
- **NEVER** carry the tool by the air line.
- **NEVER** spray flammable substances near open flames or sources of heat and ignition. **DO NOT** smoke in the vicinity of this product.

## 5. Identification

Carefully remove the product from the packaging and examine it for any signs of damage that may have occurred during shipment. If any part is damaged or

missing, do not attempt to use the product. Please contact the Draper Helpline; contact details can be found at the back of this manual.



- (1) Air nozzle
- (2) Handle
- (3) 1/4" BSP air inlet connector
- (4) Trigger

- (5) Tube/paint tin connector
- (6) 500mm flexible spraying nozzle

Please visit **drapertools.com** for our full range of accessories and consumables.

## 6. Maintenance, Storage and Disposal



**WARNING! ALWAYS ensure that the tool is disconnected from the air supply and that the air supply is switched off before attempting to adjust or maintain this product.**

- Keep the coating gun clean and dry when not in use.
- Store in a clean dry place and out of the reach of children.

At the end of its working life, dispose of the product responsibly and in line with local regulations. Recycle where possible.

- **DO NOT** incinerate.
- Dispose of paint separately and in accordance with local regulations; **DO NOT** abandon it in the environment.



## 7. Warranty

6 months from date of purchase - visit [drapertools.com/warranty](https://www.drapertools.com/warranty) for full details.

## 8. Symbols



Read the instruction manual



**Warning!**



Do not incinerate or throw onto fire



Do not abandon in the environment



Wear face mask and safety glasses

## Contact Details

### Draper Tools

Draper Tools Limited  
Hursley Road, Chandler's Ford  
Eastleigh, Hampshire  
SO53 1YF  
UK

**Website:** [drapertools.com](https://www.drapertools.com)

**Email:** [sales@drapertools.com](mailto:sales@drapertools.com)

**Product Helpline:** +44 (0) 23 8049 4344

**Telephone Sales Desk:** +44 (0) 23 8049 4333

**General Enquiries:** +44 (0) 23 8026 6355

### Delta International

Delta International BV  
Oude Graaf 8  
6002 NL  
Weert  
Netherlands

Please contact the Draper Tools Product Helpline for repair and servicing enquiries.