




SELF RETRACTING SAFETY KNIFE

30969 – INSTRUCTIONS FOR USE

1. Operating the knife


Fig. 1



Press the lever (1) to extend the blade.


Note: The blade will automatically retract when the blade is lifted off the workpiece.

Fig. 2




After use, push the catch (2) to retain the blade safely inside the housing.

2. Changing the blade




Press the blade release button (3).



Press the lever (1) and hold.

Always use a pair of pliers to hold the blade when removing and fitting. Release the lever (1) to retract the blade.



Then press the blade locking button (4).