

## **Track Rod Removal Tool**

Stock No.27814
INSTRUCTIONS

Part No.TRRT-A 09/2012

Always refer to the vehicle manufacturer's handbook or Haynes manual before dismantling as some vehicles must be put into a service mode. Failure to comply with the vehicle manufacturers service procedure can result in steering loss. Draper Tools Ltd accepts no responsibility for incorrectly installed steering components.

## 1. SPECIFICATION

Stock no.	
Part no	TRRT-A
Head application diameter	
Hollow length body	400mm (approx.)
Drive ends	
Hex	27mm (outer)
Square drive	½" (inner)

## 2. INSTRUCTION FOR USE

- Once access has been gained to the track rod, allow the track rod to pass through the hollow body (A) until the head of the tool (B) meets the steering joint (C).
- Using either a 27mm spanner or  $\frac{1}{2}$ " square drive, turn tool anti-clockwise to loosen the steering joint.

