


SELF PROPELLED PETROL LAWN MOWER

08671 – LMP410SP SPARE PARTS DRAWING






SELF PROPELLED PETROL LAWN MOWER

08671 – LMP410SP SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION	KEY No.	PART No.	STOCK No.	DESCRIPTION
1	Y-LMP390-1E		The crankshaft box body	42	Y-LMP390-42E	56509	Valve push rod
2	Y-LMP390-2E	54584	Oil gauge assembly	43	Y-LMP390-43E	56510	Limit plate assembly
3	Y-LMP390-3E	54586	Valve lifter	44	Y-LMP390-44E	56511	Inlet valve
4	Y-LMP390-4E	54610	Rocker arm	45	Y-LMP390-45E	56512	Exhaust valve
5	Y-LMP390-5E	54723	Rocker arm fastening bolt assembly	47	Y-LMP390-47E	56514	Carburetor assembly
6	Y-LMP390-6E	54986	Valve springs	48	Y-LMP390-48E	56515	Intake gasket
7	Y-LMP390-7E	54987	Inlet valve spring seat	49	Y-LMP390-49E	56516	Carburetor connection block
8	Y-LMP390-8E	55084	Circular plate	50	Y-LMP390-50E	56517	Add pump
9	Y-LMP390-9E	55085	Valve oil seal	51	Y-LMP390-51E	56518	Carburetor gasket
10	Y-LMP390-10E	55438	Oil drain bolt m10x1.25X15	52	Y-LMP390-52E	56520	Muffler
11	Y-LMP390-11E	55442	Stud m6x77	53	Y-LMP390-53E	56521	Muffler housing
12	Y-LMP390-12E	55446	Stud m6x100	54	Y-LMP390-54E	56522	Start the tray assembly
13	Y-LMP390-13E	55450	Oil drain bolt washer	55	Y-LMP390-55E	56523	In the hood
14	Y-LMP390-14E	55455	Crankshaft oil seal	56	Y-LMP390-56E	56524	Speed regulating spring b
15	Y-LMP390-15E	55456	Crankshaft flat mat	57	Y-LMP390-57E	56525	Vernier c spring
16	Y-LMP390-16E	55515	Positioning pin of crankcase	58	Y-LMP390-58E	56526	Throttle lever
17	Y-LMP390-17E	56106	Spark plug	59	Y-LMP390-59E	56527	Swinging rod
18	Y-LMP390-18E	56114	Check back clip	60	Y-LMP390-60E	56529	Speed control controller
19	Y-LMP390-19E	56116	Bolt m6x16	61	Y-LMP390-61E	56531	Control arm
20	Y-LMP390-20E	56117	Bolt m6x18	62	Y-LMP390-62E	56532	Fuel tank
21	Y-LMP390-21E	56192	Bolt m6x25	63	Y-LMP390-63E	56533	Cap
22	Y-LMP390-22E	56193	Nut m12x1. 25	64	Y-LMP390-64E	56536	Igniter
23	Y-LMP390-23E	56196	Nut m6	65	Y-LMP390-65E	56537	Flywheel components
24	Y-LMP390-24E	56449	Nut m6	66	Y-LMP390-66E	56538	Brake components
25	Y-LMP390-25E	56451	Breathing valve spring	67	Y-LMP390-67E	56539	Oil return chamber cover gasket
26	Y-LMP390-26E	56452	Pendulum stem seal	68	Y-LMP390-68E	56540	Start cover stud
27	Y-LMP390-27E	56453	Air filter gasket	69	Y-LMP390-69E	56541	Start cover stud
28	Y-LMP390-28E	56468	Crankshaft oil seal	70	Y-LMP390-70E	56543	Tank stud
29	Y-LMP390-29E	56470	Centrifugal governor gear assembly	71	Y-LMP390-71E	56544	Fuel pipe
30	Y-LMP390-30E	56471	Cylinder cranium	72	Y-LMP390-72E	56545	Exhaust gasket
31	Y-LMP390-31E	56472	Exhaust pipe	73	Y-LMP390-73E	56546	Fuel pipe clamp
32	Y-LMP390-32E	56499	Crankcase cover	74	Y-LMP390-74E	56547	Filter
33	Y-LMP390-33E	56500	Piston	75	Y-LMP390-75E	56551	Cylinder head cover gasket
34	Y-LMP390-34E	56501	Piston pin	76	Y-LMP390-76E	56552	Start the cup
35	Y-LMP390-35E	56502	Piston pin retainer	77	Y-LMP390-77E	56554	The impeller
36	Y-LMP390-36E	56503	Piston ring assembly				
37	Y-LMP390-37E	56504	Connecting rod component				
38	Y-LMP390-38E	56505	Crankshaft timing driving gear				
39	Y-LMP390-39E	56506	The crankshaft				
40	Y-LMP390-40E	56507	Back to the oil chamber				
41	Y-LMP390-41E	56508	Camshaft assembly				

SELF PROPELLED PETROL LAWN MOWER

08671 – LMP410SP SPARE PARTS DRAWING





SELF PROPELLED PETROL LAWN MOWER

08671 – LMP410SP SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1	Y-LMP410SP-1D	56600	Bolt 3/8-24unfx38
2	Y-LMP410SP-2D	56602	Flat washer
3	Y-LMP410SP-3D	56603	Blade washer
4	Y-LMP410SP-4D	56606	Blade
5	Y-LMP410SP-5D	56609	Blade adapter
6	Y-LMP410SP-6D	56749	Left gear assy
7	Y-LMP410SP-7D	56767	Height-adjusting handle bar assembly
8	Y-LMP410SP-8D	56775	Bolt m6x16
9	Y-LMP410SP-9D	56777	Belt cover
10	Y-LMP410SP-10D	57383	Nut gb6183 m6
11	Y-LMP410SP-11D	57384	Initiative pulley
12	Y-LMP410SP-12D	57387	Bolt m6x7
13	Y-LMP410SP-13D	57648	Belt v gb11544
14	Y-LMP410SP-14D	57664	Screw
15	Y-LMP410SP-15D	58420	Key
16			Deck
17	Y-LMP410SP-17D	58580	Front axle plank
18	Y-LMP410SP-18D	58587	Bolt m6x12
19	Y-LMP410SP-19D	59805	Screw
20	Y-LMP410SP-20D	60488	Screw m6*16
21	Y-LMP410SP-21D	60511	Soft grip
22	Y-LMP410SP-22D	60549	Engine dvo130
23	Y-LMP410SP-23D	60557	Rear axle plank
24	Y-LMP410SP-24D	60558	Cable protecting bush
25	Y-LMP410SP-25D	60752	Washer
26	Y-LMP410SP-26D	61156	Back panel
27	Y-LMP410SP-27D	61302	Nut gb6183 m8
28	Y-LMP410SP-28D	61306	Bolt
29	Y-LMP410SP-29D	61321	Stem
30	Y-LMP410SP-30D	61587	Circlip
31	Y-LMP410SP-31D	61588	Torsional spring (l)
32	Y-LMP410SP-32D	61589	Axle(rear cover)
33	Y-LMP410SP-33D	61590	Rear cover
34	Y-LMP410SP-34D	61591	Torsional spring (r)
35	Y-LMP410SP-35D	61592	Bolt m8x20
36	Y-LMP410SP-36D	61593	Left handle support
37	Y-LMP410SP-37D	61594	Triangle knob
38			Lower handle
39	Y-LMP410SP-39D	61595	Clip
40	Y-LMP410SP-40D	61596	Nylon collar

KEY No.	PART No.	STOCK No.	DESCRIPTION
41			Upper handle
42	Y-LMP410SP-42D	61597	Bolt
43	Y-LMP410SP-43D	61598	Brake level
44	Y-LMP410SP-44D	61599	Driver level
45	Y-LMP410SP-45D	61600	Rope guide support
46	Y-LMP410SP-46D	61601	Bolt m6
47	Y-LMP410SP-47D	61602	Clip,wire harness
48	Y-LMP410SP-48D	61603	Nut m6
49	Y-LMP410SP-49D	61604	Self-propelled cable
50	Y-LMP410SP-50D	61605	Height adjuster cover
51	Y-LMP410SP-51D	61606	Return spring
52	Y-LMP410SP-52D	61607	Right handle support
53	Y-LMP410SP-53D	61608	Bolt m6x14
54	Y-LMP410SP-54D	61609	Frame
55	Y-LMP410SP-55D	61610	Grass bag
56	Y-LMP410SP-56D	61611	Wheel cover
57	Y-LMP410SP-57D	61612	Nut gb6182 m10
58	Y-LMP410SP-58D	61613	Front wheel
59	Y-LMP410SP-59D	61614	Flat washer
60	Y-LMP410SP-60D	61615	Front axle
61	Y-LMP410SP-61D	61616	Hold hoop
62	Y-LMP410SP-62D	61617	Wheel cover
63	Y-LMP410SP-63D	61618	Rear wheel
64	Y-LMP410SP-64D	61619	Circlip
65	Y-LMP410SP-65D	61620	Right gear assy
66	Y-LMP410SP-66D	61622	Inner wheel cover
67	Y-LMP410SP-67D	61623	Transmission gear pin gb119.2
68	Y-LMP410SP-68D	61624	Rear axle
69	Y-LMP410SP-69D	61625	Nut gb6182 m6
70	Y-LMP410SP-70D	61626	Gear box
71	Y-LMP410SP-71D	61627	Height adjustment link bar
72	Y-LMP410SP-72D	61628	Height adjuster spring
73	Y-LMP410SP-73D	61629	Fixed bolt
74	Y-LMP410SP-74D	61771	Brake cable

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355 internet: drapertools.com email: sales@drapertools.com