


SELF PROPELLED PETROL LAWN MOWER

08673 – LMP510 SPARE PARTS DRAWING





SELF PROPELLED PETROL LAWN MOWER


08673 – LMP510 SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1	Y-LMP510-1E	62849	Bolt m6x12
2	Y-LMP510-2E	63957	Cover comp, cylinder head
3	Y-LMP510-3E	63958	Packing, headcover
4	Y-LMP510-4E	64104	Rocker arm
5	Y-LMP510-5E	64211	Plate, push rod guide
6	Y-LMP510-6E	64611	Seat, valve spring, in
7	Y-LMP510-7E	64612	Spring, valve
8	Y-LMP510-8E	64719	Returner, intake valve
9	Y-LMP510-9E	64943	Valve, intake
10	Y-LMP510-10E	65256	Valve exhaust
11	Y-LMP510-11E	65306	Spark pulg
12	Y-LMP510-12E	65383	Enriched air line
13	Y-LMP510-13E	65384	Bolt m6x25
14	Y-LMP510-14E	65387	Circular plate
15	Y-LMP510-15E	65981	Plate, governor
16	Y-LMP510-16E	66272	Rod, push
17	Y-LMP510-17E	67129	Lifter, valve
18	Y-LMP510-18E	67829	Camshaft assy
19	Y-LMP510-19E	68147	Scraper ring set, piston
20	Y-LMP510-20E	68148	Piston
21	Y-LMP510-21E	68612	Pin, piston
22	Y-LMP510-22E	68630	Clip, piston
23	Y-LMP510-23E	68679	Rod assembly, connecting
24			Cylinder
25	Y-LMP510-25E	68707	Oil seal
26	Y-LMP510-26E	68752	Nut, flange m6
27	Y-LMP510-27E	69000	Adjuster rocker arm
28	Y-LMP510-28E	69021	Shroud
29	Y-LMP510-29E	69072	Breather valve spring
30	Y-LMP510-30E	69656	Filter, breather
31	Y-LMP510-31E	69740	Muffler assy
32	Y-LMP510-32E	69772	Bolt, stud
33	Y-LMP510-33E	71081	Fuel tank cap comp
34	Y-LMP510-34E	71131	Fuel tank
35	Y-LMP510-35E	71136	Tank pads
36	Y-LMP510-36E	71137	Start small cap
37	Y-LMP510-37E	71185	Bolt m6x16
38	Y-LMP510-38E	71212	Filter
39	Y-LMP510-39E	71383	Ablausschraube
40	Y-LMP510-40E	71873	Fuel line
41	Y-LMP510-41E	71938	Shaft, governor arm
42	Y-LMP510-42E	73028	Washer, governor arm shaft
43	Y-LMP510-43E	73324	Seal, governor arm shaft
44	Y-LMP510-44E	73335	Pin, lock
45	Y-LMP510-45E	73356	Governor arm
46	Y-LMP510-46E	73360	Drain bolt washer

KEY No.	PART No.	STOCK No.	DESCRIPTION
47	Y-LMP510-47E	73731	Disc nut m6
48	Y-LMP510-48E	73806	Rod, governor
49	Y-LMP510-49E	74078	Spring, throttl return
50	Y-LMP510-50E	74084	Spring, governor
51	Y-LMP510-51E	74232	Nut
52	Y-LMP510-52E	75103	Shroud assy, upper
53	Y-LMP510-53E	75104	Tube, breather
54	Y-LMP510-54E	75554	Gasket, exhaust
55	Y-LMP510-55E	76064	The crankshaft
56	Y-LMP510-56E	76066	Nut
57	Y-LMP510-57E	76067	Washer, crankshaft
58	Y-LMP510-58E	76068	Governor assembly
59	Y-LMP510-59E	76069	Gasket, breather chamber
60	Y-LMP510-60E	76071	Cap, breather chamber
61	Y-LMP510-61E	76072	Dowel pin, casecover
62			Cover assembly, crankcase
63	Y-LMP510-63E	76073	Oil seal
64	Y-LMP510-64E	76075	Bolt m6x18
65	Y-LMP510-65E	76076	Bolt m6x45
66	Y-LMP510-66E	76077	In the hood
67	Y-LMP510-67E	76078	Clip, fuel line
68	Y-LMP510-68E	76079	Dipstick
69	Y-LMP510-69E	76080	Nut m6
70	Y-LMP510-70E	76081	Brake assembly
71	Y-LMP510-71E	76082	Ignition coil assy
72	Y-LMP510-72E	76083	Bolt stud, ignition coil
73	Y-LMP510-73E	76085	Bolt stud, recoil starter
74	Y-LMP510-74E	76086	Flywheel assembly
75	Y-LMP510-75E	76087	Fan, recoil starter
76	Y-LMP510-76E	76088	Pulley, starter
77	Y-LMP510-77E	76089	Nut m14
78	Y-LMP510-78E	76090	Shield, muffler
79	Y-LMP510-79E	76091	Air filter gasket
80	Y-LMP510-80E	76092	Air cleaner assembly
81	Y-LMP510-81E	76094	Bolt, stud
82	Y-LMP510-82E	76095	Packing, intake
83	Y-LMP510-83E	76096	Insulator, carburetor
84	Y-LMP510-84E	76097	Packing, carburetor
85	Y-LMP510-85E	76099	Carburetor assy
86	Y-LMP510-86E	76102	Clip, fuel line
87	Y-LMP510-87E	76103	Clip, fuel line
88	Y-LMP510-88E	76104	Screw m4x8
89	Y-LMP510-89E	76105	Q type line card
90	Y-LMP510-90E	76106	Bolt stud, recoil starter
91	Y-LMP510-91E	76117	Wind deflector

SELF PROPELLED PETROL
LAWN MOWER

08673 – LMP510 SPARE PARTS DRAWING





SELF PROPELLED PETROL LAWN MOWER

08673 – LMP510 SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1	Y-LMP510-1D	76118	Bolt BS1768 3/8-24UNFx38
2	Y-LMP510-2D	76119	Flat washer
3	Y-LMP510-3D	76195	Washer
4	Y-LMP510-4D	76207	Blade
5	Y-LMP510-5D	76930	Blade adapter
6	Y-LMP510-6D	76931	The metal clip
7	Y-LMP510-7D	76939	Flywheel nut m14x1.5
8	Y-LMP510-8D	77182	Bolt m6x16
9	Y-LMP510-9D	78213	Belt cover
10	Y-LMP510-10D	78214	Bolt m6
11	Y-LMP510-11D	78280	Initiative pulley
12	Y-LMP510-12D	78465	Front cover handle
13	Y-LMP510-13D	78466	Belt v
14	Y-LMP510-14D	78469	Screw kal50x12
15	Y-LMP510-15D	78710	Bolt m8x30
16	Y-LMP510-16D	78929	Woodruff key
17			Deck
18	Y-LMP510-18D	78978	Decorative cover (front)
19	Y-LMP510-19D	79188	Bolt m8x30
20	Y-LMP510-20D	79336	Glove assembly
21	Y-LMP510-21D	80007	Washer 8.4*24*2
22	Y-LMP510-22D	80031	Engine dvo175
23	Y-LMP510-23D	80147	Circlip
24	Y-LMP510-24D	80329	Torsional spring (rear cover)
25	Y-LMP510-25D	80330	Axle(rear cover)
26	Y-LMP510-26D	80716	Plastic part
27	Y-LMP510-27D	80717	Cable protection pipe Ø16
28	Y-LMP510-28D	80718	Rear cover
29	Y-LMP510-29D	86080	Nut m8
30	Y-LMP510-30D	86866	Stem
31	Y-LMP510-31D	86867	Gearbox
32	Y-LMP510-32D	86871	Mulching plug
33	Y-LMP510-33D	86872	Back panel
34	Y-LMP510-34D	86874	Bolt m8x20
35	Y-LMP510-35D	86877	Left handle support
36	Y-LMP510-36D	86882	Bolt m6x14
37	Y-LMP510-37D	86935	Fixed bolt m8x68
38	Y-LMP510-38D	86937	Fixed pin
39	Y-LMP510-39D	86938	Handle fast fix
40	Y-LMP510-40D	87384	Clip
41			Lower handle
42	Y-LMP510-42D	87457	Triangle knob
43			Upper handle
44	Y-LMP510-44D	87808	Bolt m6x35
45	Y-LMP510-45D	87986	Gasket 8.4*16*1.4
46	Y-LMP510-46D	87987	Soft grip

KEY No.	PART No.	STOCK No.	DESCRIPTION
47	Y-LMP510-47D	87988	Clutch lever
48	Y-LMP510-48D	88154	Nut m6
49	Y-LMP510-49D	88918	Rope guide support
50	Y-LMP510-50D	88925	O-rings
51	Y-LMP510-51D	88928	Nut m6
52	Y-LMP510-52D	88930	Wash mouth
53	Y-LMP510-53D	88933	Clutch and brake cable
54	Y-LMP510-54D	88986	Tension tension spring
55	Y-LMP510-55D	89216	Clippings bag bracket
56	Y-LMP510-56D	89291	The control panel
57	Y-LMP510-57D	89292	Right handle support
58	Y-LMP510-58D	89720	Bolt m5x30
59	Y-LMP510-59D	89779	Nut m5
60	Y-LMP510-60D	89821	Grass catcher bag
61	Y-LMP510-61D	89822	Rear axle plank (r)
62	Y-LMP510-62D	89823	Screw st6.3x16f
63	Y-LMP510-63D	89826	Gear pin(transmission)
64	Y-LMP510-64D	89827	Brake level
65	Y-LMP510-65D	89828	Side cover assembly
66	Y-LMP510-66D	91199	Side discharge chute
67	Y-LMP510-67D	91438	Torsional spring
68	Y-LMP510-68D	92184	Bracket(side discharge cover)
69	Y-LMP510-69D	92416	Axle(side discharge cover)
70	Y-LMP510-70D	92417	Heigh adjuster plank
71	Y-LMP510-71D	92480	Wheel cover
72	Y-LMP510-72D	92496	Nut m10x1.5
73	Y-LMP510-73D	92499	Front wheel
74	Y-LMP510-74D	92501	Washer
75	Y-LMP510-75D	92504	Fixed bolt
76	Y-LMP510-76D	92505	Height adjustment link bar
77	Y-LMP510-77D	92516	Bolt m8x45
78	Y-LMP510-78D	92521	Nut m6
79	Y-LMP510-79D	92522	Hold hoop
80	Y-LMP510-80D	92523	Front wheel axle
81	Y-LMP510-81D	92525	Bolt m6x50
82	Y-LMP510-82D	92528	Wheel cover
83	Y-LMP510-83D	92537	Rear wheel
84	Y-LMP510-84D	92538	Circlip
85	Y-LMP510-85D	92539	Right gear assy
86	Y-LMP510-86D	92551	Inner wheel cover
87	Y-LMP510-87D	92552	Ball bearing 12.7* 28.6
88	Y-LMP510-88D	92553	Rear wheel axle
89	Y-LMP510-89D	92561	Bolt m6
90	Y-LMP510-90D	92562	Height adjuster spring
91	Y-LMP510-91D	92563	Hold hoop
92	Y-LMP510-92D	92565	Left gear assy

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355 internet: drapertools.com email: sales@drapertools.com