



SELF PROPELLED PETROL

LAWN MOWER

08674 – LMP530 SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1	Y-LMP530-1D	44118	Bolt - 24 UNFx38 3/8
2	Y-LMP530-2D	44119	Dish washer
3	Y-LMP530-3D	44120	Blade isolation pad Ø 35
4	Y-LMP530-4D	44121	Blade
5	Y-LMP530-5D	44122	Knife holder
6	Y-LMP530-6D	44123	Battery door reset spring
7	Y-LMP530-7D	44124	Woodruff key
8	Y-LMP530-8D	44126	Bolt with disc M6 x 16
9	Y-LMP530-9D	44127	Belt cover
10	Y-LMP530-10D	44128	Nut M6
11	Y-LMP530-11D	44129	Variable speed driving belt pulley
12	Y-LMP530-12D	44130	Self tapping screw
13	Y-LMP530-13D	45908	Belt
14	Y-LMP530-14D	45963	Self-tapping screw KAL50x12
15	Y-LMP530-15D	45989	Lithium battery startup switch
16	Y-LMP530-16D	48593	Self-tapping screw ST6.3*32
17	Y-LMP530-17D	48651	Cutting plate
18	Y-LMP530-18D	48706	Hood
19	Y-LMP530-19D	48864	Screw
20	Y-LMP530-20D	48869	Bolt M8x30
21	Y-LMP530-21D	48870	Gasket PHI 8.4 * 24 * 2
22	Y-LMP530-22D	48872	Engine DV173
23	Y-LMP530-23D	50765	Open ring
24	Y-LMP530-24D	50766	Torsion spring for rear cover plate
25	Y-LMP530-25D	50774	Hougaiban shaft
26	Y-LMP530-26D	50776	Chassis block
27	Y-LMP530-27D	50792	Lap-rope sheath. 16
28	Y-LMP530-28D	50801	Hougaiban
29	Y-LMP530-29D	51064	Nut M8
30	Y-LMP530-30D	51279	Lithium battery wiring harness
31	Y-LMP530-31D	51435	Bolt M8*45
32	Y-LMP530-32D	51920	After the plug
33	Y-LMP530-33D	51931	After the air duct
34	Y-LMP530-34D	51932	Bolt with disc M8 x 20
35	Y-LMP530-35D	52431	Left arm rest
36	Y-LMP530-36D	52432	Bolt M6x14
37	Y-LMP530-37D	52433	Quick lock handle
38	Y-LMP530-38D	52434	Locking pin shaft
39	Y-LMP530-39D	52435	Lithium electric limit spring

KEY No.	PART No.	STOCK No.	DESCRIPTION
40	Y-LMP530-40D	52436	Wire clip
41	Y-LMP530-41D		Push rod
42	Y-LMP530-42D	52438	Triangle knob
43	Y-LMP530-43D		Push rod
44	Y-LMP530-44D	52439	Metal clip
45	Y-LMP530-45D	52440	Line pressing block
46	Y-LMP530-46D	52441	Push rod bushing
47	Y-LMP530-47D	52442	Drive rod
48	Y-LMP530-48D	52443	Disc nut M6
49	Y-LMP530-49D	52446	Pull rope
50	Y-LMP530-50D	52447	Front cover handle
51	Y-LMP530-51D	52448	Cap nut M6
52	Y-LMP530-52D	52449	Lithium battery startup panel
53	Y-LMP530-53D	52450	Drive flameout double cable
54	Y-LMP530-54D	52451	Tension tension spring
55	Y-LMP530-55D	52452	Clippings bag bracket
56	Y-LMP530-56D	52453	Push down plug
57	Y-LMP530-57D	52454	Right arm rest bracket assembly
58	Y-LMP530-58D	52455	Quick lock bolt M8x68
59	Y-LMP530-59D	52456	Wash mouth
60	Y-LMP530-60D	52457	Grass catcher bag
61	Y-LMP530-61D	52458	Rear axle right plate
62	Y-LMP530-62D	52459	Self-tapping screw ST6.3X16F
63	Y-LMP530-63D	52460	O-rings Ø Ø 11.2 X 2.65
64	Y-LMP530-64D	52462	Gasket Ø 16 x 8.4 X 1.4
65	Y-LMP530-65D	52463	Side cover assembly
66	Y-LMP530-66D	52464	Side exhaust duct
67	Y-LMP530-67D	52466	Twisted spring for side cover plate
68	Y-LMP530-68D	52467	Side cover bracket
69	Y-LMP530-69D	52468	Side cover plate shaft
70	Y-LMP530-70D	52469	Self-tapping screw ST3.0*12
71	Y-LMP530-71D	52470	Wheel cover
72	Y-LMP530-72D	52471	Nut M10 x 1.5
73	Y-LMP530-73D	52472	Push wheel
74	Y-LMP530-74D	52473	Wave washer
75	Y-LMP530-75D	52474	Connecting rod fixing bolt
76	Y-LMP530-76D	52475	Connecting rod
77	Y-LMP530-77D	52476	Open ring
78	Y-LMP530-78D	52477	Nut M6

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355 internet: drapertools.com email: sales@drapertools.com



SELF PROPELLED PETROL

LAWN MOWER


08674 – LMP530 SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
79	Y-LMP530-79D	52478	Front axle lower seat
80	Y-LMP530-80D	52480	Front axle
81	Y-LMP530-81D	52481	Bolt with disc M6 x 50
82	Y-LMP530-82D	52482	Wheel cover
83	Y-LMP530-83D	52483	Since the go round
84	Y-LMP530-84D	52484	Shaft with elastic open collar Ø 12
85	Y-LMP530-85D	52486	Right output gear
86	Y-LMP530-86D	52490	Dustproof wheel cover
87	Y-LMP530-87D	52491	Non-standard bearings Ø 12.7 * 28.6
88	Y-LMP530-88D	52492	After the shaft
89	Y-LMP530-89D	52493	Nut M6
90	Y-LMP530-90D	52494	High tension spring
91	Y-LMP530-91D	52496	Front axle upper seat
92	Y-LMP530-92D	52497	Left output gear
93	Y-LMP530-93D	52498	Shaped bolt M6*33
94	Y-LMP530-94D	52499	Drive gear pin GB119.2
95	Y-LMP530-95D	52500	Gearbox
96	Y-LMP530-96D	52501	Magnet
97	Y-LMP530-97D	52503	Glove assembly
98	Y-LMP530-98D	52504	Heigh adjuster plank
99	Y-LMP530-99D	52505	Bolt M6*8
100	Y-LMP530-100D	52507	Lithium battery cover
101	Y-LMP530-101D	52508	Drink holder
102	Y-LMP530-102D	52509	Limit block for lithium battery
103	Y-LMP530-103D	52511	12 V wiring block
104	Y-LMP530-104D	52512	Lithium battery cover shaft
105	Y-LMP530-105D	52514	Lithium battery pack
106	Y-LMP530-106D	52515	Flywheel nut M14
107	Y-LMP530-107D	52516	Flameout lever

KEY No.	PART No.	STOCK No.	DESCRIPTION

LAWN MOWER

08674 – LMP530 SPARE PARTS DRAWING





SELF PROPELLED PETROL

LAWN MOWER

08674 – LMP530 SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1			Crankcase
2	Y-LMP530-2E	43478	Seal, governor arm shaft
3	Y-LMP530-3E	43479	Shaft, governor arm
4	Y-LMP530-4E	43480	Washer, governor arm shaft
5	Y-LMP530-5E	43481	Pin, lock
6	Y-LMP530-6E	43482	Ball bearing
7	Y-LMP530-7E	43483	Oil seal
8	Y-LMP530-8E	43484	Oil seal
9	Y-LMP530-9E	43486	Piston
10	Y-LMP530-10E	43487	Scraper ring set, piston
11	Y-LMP530-11E	43488	Rod assembly, Connecting
12	Y-LMP530-12E	43489	Pin, piston
13	Y-LMP530-13E	43490	Clip, piston
14	Y-LMP530-14E	43491	Cover assembly, crankcase
15	Y-LMP530-15E	43492	Washer, drain plug
16	Y-LMP530-16E	43493	Bolt, drain plug
17	Y-LMP530-17E	43494	Governor assembly
18	Y-LMP530-18E	43499	Bolt M6x12
19	Y-LMP530-19E	43501	Cylinder head
20	Y-LMP530-20E	43508	Valve, in
21	Y-LMP530-21E	43521	Valve exhaust
22	Y-LMP530-22E	43523	Returner, intake valve
23	Y-LMP530-23E	43526	Spring, valve
24	Y-LMP530-24E	43527	Seat, valve spring, in
25	Y-LMP530-25E	43529	Plate, push rod guide
26	Y-LMP530-26E	43530	Rocker assy
27	Y-LMP530-27E	43532	Carburetor assembly
28	Y-LMP530-28E	43534	Fuel line
29	Y-LMP530-29E	43538	Clip, fuel line
30	Y-LMP530-30E	43539	Governor arm
31	Y-LMP530-31E	43541	Bolt M6x20
32	Y-LMP530-32E	43543	Nut M6
33	Y-LMP530-33E	43545	Rod, governor
34	Y-LMP530-34E	43548	Spring, throttle return
35	Y-LMP530-35E	43550	Crankshaft assembly
36	Y-LMP530-36E	43551	Pipe, oil defense
37	Y-LMP530-37E	43553	Lifter, valve
38	Y-LMP530-38E	43572	Dowel pin, case cover
39	Y-LMP530-39E	43573	Dowel pin, case cover
40	Y-LMP530-40E	43574	Packing, case cover
41	Y-LMP530-41E	43575	Camshaft assembly
42	Y-LMP530-42E	43576	Washer, crankshaft
43	Y-LMP530-43E	43577	Bolt M8x50

KEY No.	PART No.	STOCK No.	DESCRIPTION
44	Y-LMP530-44E	43578	Filter, breather
45	Y-LMP530-45E	43579	Cover, breather valve
46	Y-LMP530-46E	43580	Adjuster rocker arm
47	Y-LMP530-47E	43581	Gasket, breather chamber
48	Y-LMP530-48E	43582	Cap, breather chamber
49	Y-LMP530-49E	43583	Pin, dowel
50	Y-LMP530-50E	43584	Gasket, cylinder head
51	Y-LMP530-51E	43585	Rod, push
52	Y-LMP530-52E	43586	Extension, oil filler
53	Y-LMP530-53E	43587	Bolt M6x30
54	Y-LMP530-54E	43588	Cover comp, cylinder head
55	Y-LMP530-55E	43589	Packing, headcover
56	Y-LMP530-56E	43590	Spark plug
57	Y-LMP530-57E	43591	Brake components
58	Y-LMP530-58E	43593	Fuel tank cap comp
59	Y-LMP530-59E	43594	Dipstick
60	Y-LMP530-60E	43595	Flywheel assembly
61	Y-LMP530-61E	43596	Fan, recoil starter
62	Y-LMP530-62E	43597	Pulley, starter
63	Y-LMP530-63E	43598	Nut
64	Y-LMP530-64E	43599	Breather valve spring
65	Y-LMP530-65E	43600	Ignition coil assy
66	Y-LMP530-66E	43601	Bolt stud, ignition coil
67	Y-LMP530-67E	43602	Bolt stud, recoil starter
68	Y-LMP530-68E	43603	Bolt, stud
69	Y-LMP530-69E	43604	Packing, intake
70	Y-LMP530-70E	43605	Insulator, carburetor
71	Y-LMP530-71E	43606	Packing, carburetor
72	Y-LMP530-72E	43607	Gasket, air cleaner
73	Y-LMP530-73E	43608	Shroud assy, upper
74	Y-LMP530-74E	43626	Clip, wire harness
75	Y-LMP530-75E	43627	Spring, governor
76	Y-LMP530-76E	73628	Tube, breather
77	Y-LMP530-77E	43629	Air cleaner assembly
78	Y-LMP530-78E	43630	Hood, fan
79	Y-LMP530-79E	43631	Clip, fuel line
80	Y-LMP530-80E	43632	Cover, fan
81	Y-LMP530-81E	43633	Nut M6
82	Y-LMP530-82E	43634	Fuel tank assembly
83	Y-LMP530-83E	43695	Wind deflector
84	Y-LMP530-84E	43696	Bolt M4*8
85	Y-LMP530-85E	43697	Bolt M8x20
86	Y-LMP530-86E	43698	Bolt stud, recoil starter
87	Y-LMP530-87E	43992	Bolt, stud
88	Y-LMP530-88E	43995	Packing, exhaust

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355 internet: drapertools.com email: sales@drapertools.com

