




25.4cc 250mm

PETROL CHAINSAW

15042 - CSP2625 SPARE PARTS DRAWING





25.4cc 250mm

PETROL CHAINSAW

15042 - CSP2625 SPARE PARTS LISTING

Key No.	Part No.	Stock No.	Description	Key No.	Part No.	Stock No.	Description
1	YCSP2625-01	15129	Crank shaft assembly	42	YCSP2625-42	15172	Screw st5.5 × 15
2	YCSP2625-02	15130	Needle bearing ball	43	YCSP2625-43	15173	Oil pump sponge washer
3	YCSP2625-03	15131	Ring snap	44	YCSP2625-44	15174	Oil pump washer
4	YCSP2625-04	15132	Piston	45	YCSP2625-45	15175	Oil pump
5	YCSP2625-05	15133	Piston pin	46	YCSP2625-46	15176	Chain oil outlet pipe
6	YCSP2625-06	15134	Snap ring	47	YCSP2625-47	15177	Oil pump washer
7	YCSP2625-07	15135	Piston ring	48	YCSP2625-48	15178	Oil pump shield
8	YCSP2625-08	15136	Woodruff key 3 × 10	49	YCSP2625-49	15179	Worm gear
9	YCSP2625-09	15137	Ball bearing 6001	50	YCSP2625-50	15180	Needle bearing
10	YCSP2625-10	15138	Right oil ring 12 × 22 × 4.5	51	YCSP2625-51	15181	Drum clutch cover
11	YCSP2625-11	15139	Left oil ring 12 × 22 × 6	52	YCSP2625-52	15182	Drum clutch washer
12	YCSP2625-12	15140	Fly wheel	53	YCSP2625-53	15183	Clutch support
13	YCSP2625-13	15141	Screw m8 × 1	54	YCSP2625-54	15184	Drum clutch spring
14	YCSP2625-14	15142	Cylinder	55	YCSP2625-55	15185	Clutch retainer
15	YCSP2625-15	15143	Support cylinder	56	YCSP2625-56	15186	Carburetor oil vacuole
16	YCSP2625-16	15144	Screw m5 × 20	57	YCSP2625-57	15187	Intake boot
17	YCSP2625-17	15145	Washer muffler	58	YCSP2625-58	15188	Oil hose tie in
18	YCSP2625-18	15146	Muffler	59	YCSP2625-59	15189	Oil return tube
19	YCSP2625-19	15147	Shield muffler	61	YCSP2625-61	15190	Air gasket hose
20	YCSP2625-20	15148	Screw m5 × 40	62	YCSP2625-62	15191	Bar plate
21	YCSP2625-21	15149	Spark plug	63	YCSP2625-63	15192	Screw st4.2 × 11
22	YCSP2625-22	15150	Air hose	64	YCSP2625-64	15193	Valve vent
23	YCSP2625-23	15151	Screw m4 × 14	65	YCSP2625-65	15194	Aerate spigot snap ring
24	YCSP2625-24	15152	Electric ignition pad	66	YCSP2625-66	15195	Aerate spigot sponge
25	YCSP2625-25	15153	Electric ignition	67	YCSP2625-67	15196	Screw st5 × 13
26	YCSP2625-26	15154	Stop wire	68	YCSP2625-68	15197	Wood catcher
27	YCSP2625-27	15155	Washer 4	70	YCSP2625-70	15198	Balance support
28	YCSP2625-28	15156	Gasket 4	71	YCSP2625-71	15199	Balancer upper
29	YCSP2625-29	15157	Screw m4 × 20	72	YCSP2625-72	15200	Vent valve
30	YCSP2625-30	15158	Screw m4 × 14	73	YCSP2625-73	15201	Balancer lower
31	YCSP2625-31	15159	Screw st4.8 × 13	74	YCSP2625-74	15202	Filter
32	YCSP2625-32	15160	Safety belt	75	YCSP2625-75	15203	Clutch support
33	YCSP2625-33	15161	Screw m5 × 20	76	YCSP2625-76	15206	Oil hose
34	YCSP2625-34	15163	Crank case	77	YCSP2625-77	15207	Oil hose support
35	YCSP2625-35	15165	Hex ring spanner m5 × 14	78	YCSP2625-78	15208	Fuel cap
36	YCSP2625-36	15166	Pothook	79	YCSP2625-79	15209	Fuel gasket
38	YCSP2625-38	15168	Rubber pad	80	YCSP2625-80	15210	Fuel pat
39	YCSP2625-39	15169	Screw st4.8 × 16	81	YCSP2625-81	15211	Oil cap
40	YCSP2625-40	15170	Plug pad	82	YCSP2625-82	15218	Oil cap gasket
41	YCSP2625-41	15171	Chain catcher	83	YCSP2625-83	15219	Screw st4.8 × 16



25.4cc 250mm

PETROL CHAINSAW

15042 - CSP2625 SPARE PARTS LISTING

Key No.	Part No.	Stock No.	Description	Key No.	Part No.	Stock No.	Description
84	YCSP2625-84	15221	Oil filter toil	126	YCSP2625-149	15467	Starter assembly
85	YCSP2625-85	15388	Oil filter				
86	YCSP2625-86	15389	Chain oil hose support				
87	YCSP2625-87	15391	Ground wire				
88	YCSP2625-88	15392	Starter handle				
89	YCSP2625-89	N/A	Rope starter				
90	YCSP2625-90	N/A	Guide bush rope				
91	YCSP2625-91	N/A	Screw St4.2 × 16				
92	YCSP2625-92	N/A	Housing starter				
93	YCSP2625-93	N/A	Baffler fan				
94	YCSP2625-94	N/A	Hose seat fan				
95	YCSP2625-95	N/A	Spring starter				
96	YCSP2625-96	N/A	Cover spring starter				
97	YCSP2625-97	N/A	Pulley starter				
98	YCSP2625-98	N/A	GB/T96 Washers (5 × 16)				
99	YCSP2625-99	15396	Paper gasket				
100	YCSP2625-100	15397	Cover top				
101	YCSP2625-101	15398	Rear handle				
102	YCSP2625-102	15399	Stop switch				
104	YCSP2625-104	15400	Trigger				
105	YCSP2625-105	15403	Trigger spring				
106	YCSP2625-106	15404	Cotter pin 5 × 25				
107	YCSP2625-107	15409	Trigger safety lever				
108	YCSP2625-108	15411	Rear handle cover				
109	YCSP2625-109	15412	Carburettor oil hose				
110	YCSP2625-110	15414	Carburettor hose pilse				
112	YCSP2625-112	15417	Carburettor				
113	YCSP2625-113	15418	Carburettor sponge				
114	YCSP2625-114	15419	Air filter-a				
115	YCSP2625-115	15420	Air filter cover				
116	YCSP2625-116	15421	Plate				
117	YCSP2625-117	15424	Screw st4.8 × 16				
118	YCSP2625-118	15425	Screw m5 × 44				
119	YCSP2625-119	15426	Air filter-b				
120	YCSP2625-120	15427	Air filter cover				
121	YCSP2625-121	15428	Air filter knob				
122	YCSP2625-122	15429	Choke knob grommet				
123	YCSP2625-123	15430	Choke knob				
124	YCSP2625-124	15432	Throttle rod				
125	YCSP2625-125	15433	Handle				