



2.5 TONNE TROLLEY JACK

31479 – TJAS250 SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YTJAS250-1	32384	Lock nut M12
2	YTJAS250-2	32385	Front wheel washer
3	YTJAS250-3	32386	Front wheel bush
4	YTJAS250-4	32387	Front wheel
5	YTJAS250-5	32388	Side plate
6	YTJAS250-6	32389	Carrying handle
7	YTJAS250-7	32390	Screw
8	YTJAS250-8	32391	Washer
9	YTJAS250-9	32392	Retaining ring
10	YTJAS250-10	32393	Radius linkage
11	YTJAS250-11	32394	Front wheel axle
13	YTJAS250-13	32395	Tie rod
14	YTJAS250-14	32396	Lift arm
15	YTJAS250-15	32397	Saddle
16	YTJAS250-16	32399	Saddle Screw
17	YTJAS250-17	32400	Screw
18	YTJAS250-18	32401	Washer
19	YTJAS250-19	32402	Washer
20	YTJAS250-20	32404	Washer
21	YTJAS250-21	32405	Rear caster base
22	YTJAS250-22	32408	Rear caster
23	YTJAS250-23	32409	Screw
24	YTJAS250-24	32411	Lower handle

KEY No.	PART No.	STOCK No.	DESCRIPTION
25	YTJAS250-25	32412	Upper handle
26	YTJAS250-26	32414	Hydraulic unit
27	YTJAS250-27	32415	Retaining ring
28	YTJAS250-28	32417	Link block
29	YTJAS250-29	32419	Pin
30	YTJAS250-30	32420	Roller pin
31	YTJAS250-31	32422	Roller
32	YTJAS250-32	32423	Handle set screw
33	YTJAS250-33	32424	Retaining ring 12
34	YTJAS250-34	32425	Pin
36	YTJAS250-36	32426	Handle yoke
37	YTJAS250-37	32428	Handle yoke bolt
38	YTJAS250-38	32429	Tie rod
39	YTJAS250-39	32430	Rubber bumper
40	YTJAS250-40	32431	Screw
41	YTJAS250-41	32472	Linkage bolt
42	YTJAS250-42	32479	Washer
43	YTJAS250-43	32480	Screw
44	YTJAS250-44	32485	Saddle pad
45	YTJAS250-45	32492	Clip
46	YTJAS250-46	32497	Return spring
47	YTJAS250-47	32499	Universal joint

2.5 TONNE
TROLLEY JACK

31479 – TJAS250 SPARE PARTS DRAWING

