




# PETROL EARTH AUGER KIT

68294 - GPAUG52-B SPARE PARTS DRAWING





PETROL

# EARTH AUGER KIT

**68294 - GPAUG52-B SPARE PARTS LISTING**

Key No.	Part No.	Stock No.	Description	Key No.	Part No.	Stock No.	Description
1	Y-PAUG52-01	85294	Bolt	41	Y-PAUG52-41	85335	Washer
2	YGPAUG52-B-02	06502	Starter assy	42	Y-PAUG52-42	85336	Washer
3	Y-PAUG52-03	85296	Washer	43	Y-PAUG52-43	85337	Bolt
4	YGPAUG52-B-04	06503	Real starter	44	YGPAUG52-B-44	06514	Muffler cover
5	Y-PAUG52-05	85298	Washer	45	YGPAUG52-B-45	06516	Bolt
6	Y-PAUG52-06	85299	Seal oil	47	YGPAUG52-B-46	06517	Cylinder cover
7	Y-PAUG52-07	85301	Crank case (small)	48	Y-PAUG52-48	85341	Cylinder gasket
8	Y-PAUG52-08	85302	Pin	49	Y-PAUG52-49	85342	Piston ring
9	Y-PAUG52-09	85303	Needle bearing	50	Y-PAUG52-50	85343	Piston
10	Y-PAUG52-10	85304	Crankshaft	51	Y-PAUG52-51	85334	Retainer ring
11	Y-PAUG52-11	85305	Needle bearing	52	YGPAUG52-B-52	06523	Oil tank assy
12	Y-PAUG52-12	85306	Piston pin	53	Y-PAUG52-53	85346	Gum cover
13	Y-PAUG52-13	85307	Flywheel key	54	Y-PAUG52-54	85347	Plate
14	Y-PAUG52-14	85308	Crank-case gasket	55	Y-PAUG52-55	85348	Electrical ignition
15	Y-PAUG52-15	85309	Crank case (big)	56	YGPAUG52-B-56	06524	Bolt
16	Y-PAUG52-16	85310	Bolt	57	YGPAUG52-B-57	06525	Handle - gearbox assembly
17	Y-PAUG52-17	85311	Oil seal	58	YGPAUG52-B-58	06526	Cotter pin
18	Y-PAUG52-18	85312	Flywheel		AGP-AUG100	84752	100mm Auger bit
19	Y-PAUG52-19	85313	Nut	59	AGP-AUG150	84754	150mm Auger bit
20	Y-PAUG52-20	85314	Washer		AGP-AUG200	84755	200mm Auger bit
21	Y-PAUG52-21	85315	Drum clutch and spring	60	Y-PAUG52-60	85353	Pin
22	Y-PAUG52-22	85316	Washer	61	YGPAUG52-B-61	06528	Gear Box
23	Y-PAUG52-23	85317	Screw	63	Y-PAUG52-62	08421	Safety Lanyard
24	Y-PAUG52-24	85318	Cover				
26	Y-PAUG52-26	85319	Screw				
27	YGPAUG52-B-27	06504	Oil tank protect plate				
28	YGPAUG52-B-28	06506	Bolt				
29	YGPAUG52-B-29	06508	Air filter assembly				
29.5	YGPAUG52-B-29.5	06509	Air filter element				
30	YGPAUG52-B-30	06510	Bolt				
31	YGPAUG52-B-31	06511	Washer				
32	YGPAUG52-B-32	06512	Spring washer				
33	YGPAUG52-B-33	06513	Carburetor				
34	Y-PAUG52-34	85329	Carburetor washer				
35	Y-PAUG52-35	85330	Intake hose				
36	Y-PAUG52-36	85331	Intake hose washer				
37	Y-PAUG52-37	85332	Cylinder				
38	Y-GTP33-35	85251	Spark plug				
39	Y-PAUG52-39	85333	Muffler gasket				
40	Y-PAUG52-40	85334	Muffler				