


AIR IMPACT WRENCH

83964 – DAT-AIW34 SPARE PARTS LISTING




KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YDAT-AIW34-1	00392	Hammer Case
2	YDAT-AIW34-2	00393	Rubber Mat
3	YDAT-AIW34-3	00394	Anvil Bush
4	YDAT-AIW34-4	00395	Circlip
5	YDAT-AIW34-5	00396	O-Ring
6	YDAT-AIW34-6	00397	Anvil
7	YDAT-AIW34-7	00398	Hammer
8	YDAT-AIW34-8	00399	Hammer Cage

KEY No.	PART No.	STOCK No.	DESCRIPTION
9	YDAT-AIW34-9	00400	Hammer Pin
10	YDAT-AIW34-10	00401	Trigger
11	YDAT-AIW34-11	00402	Pin
12	YDAT-AIW34-12	00403	Handle
13	YDAT-AIW34-13	00404	Pin
14	YDAT-AIW34-14	00405	Bearing
15	YDAT-AIW34-15	00406	Front End Plate
16	YDAT-AIW34-16	00407	Pin

AIR IMPACT WRENCH

83964 – DAT-AIW34 SPARE PARTS LISTING



KEY No.	PART No.	STOCK No.	DESCRIPTION
17	YDAT-AIW34-17	00408	Cylinder
18	YDAT-AIW34-18	00409	Rotor
19	YDAT-AIW34-19	00410	Vane
20	YDAT-AIW34-20	00411	Rear End Plate
21	YDAT-AIW34-21	00412	Bearing
22	YDAT-AIW34-22	00413	Rubber Mat
23	YDAT-AIW34-23	00414	O-Ring
24	YDAT-AIW34-24	00415	Timing Button
25	YDAT-AIW34-25	00416	Spring
26	YDAT-AIW34-26	00417	Steel Ball
27	YDAT-AIW34-27	00418	O-Ring
28	YDAT-AIW34-28	00419	Back Cover

KEY No.	PART No.	STOCK No.	DESCRIPTION
29	YDAT-AIW34-29	00420	Fastening Screw
30	YDAT-AIW34-30	00421	Inlet Gasket
31	YDAT-AIW34-31	00422	O-Ring
32	YDAT-AIW34-32	00423	Rubber Gasket
33	YDAT-AIW34-33	00424	Inlet Valve
34	YDAT-AIW34-34	00425	Inlet Spring
35	YDAT-AIW34-35	00426	Plastic Cover
36	YDAT-AIW34-36	00427	O-Ring
37	YDAT-AIW34-37	00429	Air Inlet
38	YDAT-AIW34-38	00430	Air Inlet Screen
39	YDAT-AIW34-39	00431	Silencer Cotton