




230V 340mm BANDSAW

84715 - BS340/1100D SPARE PARTS DRAWING





230V 340mm BANDSAW

84715 - BS340/1100D SPARE PARTS LISTING

Key No.	Part No.	Stock No.	Description	Key No.	Part No.	Stock No.	Description
1-6	YBS340/1100D-3A	98636	Blade tension knob assembly	129			(NP) Flat washer
7	YBS350D-07	21557	Frame cap	130			(NP) Hex head bolt
8-12	YBS340/1100D-10A	98638	Fittings assembly #1	131			(NP) Cord bushing
13-19	YBS340/1100D-13A	98640	Fittings assembly #2	132			(NP) Limiting shaft
20	YBS350D-20	21664	Blade tension pointer	133			(NP) Hex nut
21	YBS350D-21	21669	Shoulder screw	134			(NP) Guide block
22	YBS350D-22	21691	Retaining ring	135			(NP) Lower guard
23	YBS350D-23	21692	Shaft	136			(NP) Hex head bolt
24	YBS350D-24	21693	Guide plate	137			(NP) Flat washer
25	YBS350D-25	21698	Pulling plate	138			(NP) Shaft
26	YBS350D-26	21700	Screw hex M8X1.25X16MM	139			(NP) Hex nut
27	YBS350D-27	21705	Flat washer	140			(NP) Hex head bolt
28			(NP)	141			(NP) Hex nut
29	YBS350D-29	21722	Bevel lock	142-148	YBS340/1100D-145A	98656	Lower guide block assembly
30	YBS350D-30	21724	Shaft	149-152	YBS340/1100D-151A	98657	Dust port assembly
31	YBS350D-31	21788	Bearing 6202Z	153-158	YBS340/1100D-156A	98661	Idle pulley assembly
32			(NP)	159	YBS305-159	27924	Belt
33			(NP)	160-165	YBS340/1100D-163A	98662	Motor assembly
34	YBS350D-34	21797	Retaining ring	166	YBS305-166	14235	Belt tension knob
35	YBS350D-35	21828	Tyre	167-170	YBS340/1100D-169A	98664	Table adjusting knob assembly
36			Blade	171 & 172	YBS340/1100D-171A	98666	Table assembly
37-42	YBS340/1100D-37A	98643	Upper cover assembly	173-189	YBS340/1100D-174A	98668	Table adjust assembly
43-46	YBS340/1100D-43A	98644	Lower cover assembly	190-196	YBS340/1100D-193A	98669	Angle guide assembly
47-66	YBS340/1100D-62A	98645	Switch box assembly	197			(NP) Socket head screw
67			(NP) Frame	198			(NP) Cord clamp
68-73	YBS340/1100D-72A	98647	Brush assembly	199			(NP) Flat washer
74-76	YBS340/1100D-75A	98648	Spindle pulley assembly	200			(NP) Nut
77-82	YBS340/1100D-78A	98649	Drawer assembly	201			(NP) Hex nut
83-86	YBS340/1100D-85A	98650	Switch assembly	202			(NP) LED driver
87-93	YBS340/1100D-92A	98651	Release handle assembly	203	YBS350D-203	28643	Power Cord
94-96	YBS305-94A	98618	Tracking assembly	204			(NP) Inner cord
97-101 & 105-107	YBS340/1100D-98A	98652	Protecting cover assembly	205			(NP) Flexible tube
102-104	YBS305-102A	98620	Adjusting knob assembly	206-225	YBS340/1100D-212A	98672	Fence assembly
108-123	YBS340/1100D-121A	98653	Upper guide block assembly	234	YBS305-234	14563	Push stick
124			(NP) Socket head screw	235			(NP) Hook
125			(NP) Cover lock knob	236			(NP) Hex nut
126			(NP) Guide plate	237-243	YBS340/1100D-237A	98673	Tool kit assembly
127			(NP) Lock nut				
128			(NP) Set screw				