





230V

BELT & DISC SANDER

98420 – BDS370D SPARE PARTS LISTING

| KEY No. | PART No. | STOCK No. | DESCRIPTION |
|---------|--------------|-----------|-------------------------------|
| 01 | YBDS370D-03A | 66005 | Base bottom cover assembly |
| 02 | | | |
| 03 | | | |
| 04 | YBDS370D-06A | 66006 | Disc cover assembly |
| 06 | | | |
| 05 | | | |
| 07 | | | (NP) Washer |
| 08 | | | Abrasive disc |
| 09 | YBDS370D-11A | 66252 | Disc base assembly |
| 10 | | | |
| 11 | | | |
| 12 | YBDS370D-28A | 68850 | Capacitor clamp assembly |
| 14 | | | |
| 27 | | | |
| 28 | | | |
| 29 | | | |
| 54 | | | |
| 12 | YBDS370D-59A | 69236 | Sanding belt support assembly |
| 15 | | | |
| 16 | | | |
| 30 | | | |
| 32 | | | |
| 39 | | | |
| 40 | | | |
| 41 | | | |
| 42 | | | |
| 43 | | | |
| 44 | | | |
| 45 | | | |
| 46 | | | |
| 48 | | | |
| 49 | | | |
| 50 | | | |
| 51 | | | |
| 52 | | | |
| 54 | | | |
| 55 | | | |
| 57 | | | |
| 58 | | | |
| 59 | | | |
| 61 | | | |
| 62 | | | |
| 63 | | | |
| 64 | | | |
| 65 | | | |
| 80 | | | |
| 89 | | | |
| 90 | | | |
| 12 | YBDS370D-82A | 66253 | Power cord assembly |
| 18 | | | |
| 23 | | | |
| 82 | | | |
| 82 | | | |

| KEY No. | PART No. | STOCK No. | DESCRIPTION | | | |
|---------|--------------|-----------|----------------------------------|-------------|-------|------------------|
| 13 | YBDS370D-38A | 70018 | Mitre gauge assembly | | | |
| 15 | | | | | | |
| 32 | | | | | | |
| 34 | | | | | | |
| 36 | | | | | | |
| 37 | | | | | | |
| 38 | | | | | | |
| 79 | | | | | | |
| 17 | YBDS370D-17 | 70021 | Base | | | |
| 19 | YBDS370D-22A | 70026 | Switch box assembly | | | |
| 20 | | | | | | |
| 21 | | | | | | |
| 22 | | | | | | |
| 24 | | | | | | |
| 25 | | | | | | |
| 83 | | | | | | |
| 91 | | | | | | |
| 92 | | | | | | |
| 26 | YBDS370D-81A | 70027 | Motor assembly | | | |
| 53 | | | | | | |
| 81 | | | | | | |
| 31 | YBDS370D-35A | 70031 | Work table assembly | | | |
| 32 | | | | | | |
| 33 | | | | | | |
| 34 | | | | | | |
| 35 | | | | | | |
| 47 | YBDS370D-84A | 70034 | Dust collection cover assembly | | | |
| 84 | | | | | | |
| 56 | | | (NP) Ground wire indicator plate | | | |
| 60 | YBDS370D-60A | 70036 | Back stop assembly | | | |
| 87 | | | | | | |
| 88 | | | | | | |
| 66 | YBDS370D-76A | 70065 | Belt cover assembly | | | |
| 72 | | | | | | |
| 73 | | | | | | |
| 74 | | | | | | |
| 75 | | | | | | |
| 76 | | | | | | |
| 77 | | | | | | |
| 67 | | | | YBDS370D-67 | 70039 | Drive belt cover |
| 68 | | | | | | (NP) Screw |
| 69 | | | | | | (NP) Washer |
| 70 | | | | YBDS370D-70 | 70059 | Timing belt |
| 71 | YBDS370D-71 | 70060 | Idler roller | | | |
| 78 | YBDS370D-78 | 70067 | Motor pulley | | | |
| 85 | YBDS370D-85 | 70068 | Frame support | | | |
| 86 | | | Sanding belt | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355 internet: drapertools.com email: sales@drapertools.com