



TELESCOPIC


TRESTLE

54051 and 54053 (Pair)



Assembling Instructions





Key No.	Description	Qty
1	Cross bar (680mm)	1
2	M8 x 45 hex. bolt	4
3	M8 washer	8
4	M8 hex. nut	4
5	Upright 750mm	2
6	Lower cross member 575mm	2
7	Upper cross member 575mm	1
8	'A' frame assembly	2
9	M6 x 35 pan head bolt	8
10	M6 washer	16
11	M6 hex. nut	8
12	M5 x 15 pan head bolt	2
13	M5 x 15 bolt	2
14	M5 washer	8
15	M5 hex. nut	4
16	Rubber foot	4

Assembling the Telescopic Trestle



- Locate both 'A' frames (8) and the upper cross member (7). Open out the legs on the 'A' frames and lock using the lower latch. Push in rubber feet (16) into each of the legs. Fix one end of the cross member to the 'A' frame using bolt (13), bolt (12) and the appropriate washers and nuts. Ensure that bolt (13) is used to fix the frame on the side nearest the latch, as this bolt has the shoulder to accept the locking latch. Tighten all the fixings only finger tight at this point. Fix the other end of the cross member to the other 'A' frame in the same manner again only finger tight.
- 2. Now secure the top of the 'A' frames using the short latches.
- Locate both the lower cross members (6). Fix the lower cross member between the two 'A' frames to provide the lower rigidity. Screw in the eight bolts (9) with the appropriate washers and nuts finger tight.

- 4. Locate the two uprights (5) and cross bar (1). Assemble the cross bar and uprights using the four bolts (2) with the appropriate washers and nuts finger tight. Pass the assembly down through the top of the 'A' frame using the locating pins lock in the halfway position. The pin should be passed through from the inside and when all the way through, turn down so they lock around the frame. This avoids the pin falling or getting knocked out accidentally.
- Stand the trestle on a flat and level surface and allow all parts to settle. Systematically tighten all the fixings ensuring they are fully tightened. This process should be carried out twice to ensure no fixings are left undone by mistake.

Note: Telescopic action is between 810mm - 1300mm.

Health and Safety Information



Important: DO NOT use this product if it is damaged or its structural integrity is compromised.

- Ensure that the trestle is fully assembled, and tightened before use.
- Ensure that the trestle is positioned on firm and level ground while it is in use.
- . **DO NOT** climb or stand on the trestle.

 DO NOT exceed the maximum load capacity of 250kg.

Contact Details

Draper Tools

Draper Tools Limited Hursley Road Chandler's Ford Eastleigh Hampshire SO53 1YF UK

Website: drapertools.com **Email:** sales@drapertools.com

Product Helpline: +44 (0) 23 8049 4344 **Telephone Sales Desk:** +44 (0) 23 8049 4333 **General Enquiries:** +44 (0) 23 8026 6355

Delta International Delta International BV Oude Graaf 8

6002 NL Weert

Netherlands

Please contact the Draper Tools Product Helpline for repair and servicing enquiries.