

**DRAPER**

**EN**

Original Instructions  
Version 4 - June 2025

WET & DRY

# VACUUM CLEANER

+ POWER TOOL SOCKET

**20529**



UK  
CA CE

# 1. Preface

These are the original product instructions. This document is part of the product; retain it for the life of the product, passing it on to subsequent holders. Read this manual in full before attempting to assemble, operate or maintain this product.

This Draper Tools manual describes the purpose of the product and contains all the necessary information to ensure its correct and safe use. Following all the instructions and guidance in this manual will ensure the safety of both the product and the operator and increase the lifespan of the product.

All photographs and drawings within this manual are supplied by Draper Tools to help illustrate correct operation of the product.

Every effort has been made to ensure the information contained in this manual is accurate. However, Draper Tools reserves the right to amend this document without prior warning. Always use the latest version of the product manual.

## 1.1 Product Reference

**User Manual for:** Wet & Dry Vacuum Cleaner + Power Tool Socket

**Stock No:** 20529

**Part No:** WDV30SSPA

## 1.2 Revisions

**Version 1:** September 2016  
First release

**Version 2:** January 2017

**Version 3:** February 2017

**Version 4:** June 2025

As our manuals are continually updated, always ensure that the latest version is used.

Please visit [drapertools.com/manuals](https://www.drapertools.com/manuals) for the latest version of this manual and the associated parts list, if applicable.

## 1.3 Understanding the Safety Content of This Manual



**WARNING!** – Situations or actions that may result in personal injury or death.



**CAUTION!** – Situations or actions that may result in damage to the product or surroundings.

**Important:** – Information or instructions of particular importance.

## 1.4 Copyright © Notice

Copyright © Draper Tools Limited.

Permission is granted to reproduce this manual for personal and educational use **ONLY**. Commercial copying, redistribution, hiring or lending is strictly prohibited.

No part of this manual may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited.

In all cases, this copyright notice must remain intact.

1. Preface	2	9. Maintenance and Troubleshooting	13
1.1 Product Reference	2	9.1 General Maintenance	13
1.2 Revisions	2	9.2 Troubleshooting	13
1.3 Understanding the Safety Content of This Manual	2	10. Spares, Returns and Disposal	14
1.4 Copyright © Notice	2	11. Warranty	14
2. Contents	3	12. Explanation of Symbols	15
3. Product Introduction	4		
3.1 Intended Use	4		
3.2 Specification	4		
4. Health and Safety Information	5-6		
4.1 General Health and Safety Precautions	5		
4.2 Additional Health & Safety Precautions for Vacuum Cleaners	5		
4.3 Connection to the Power Supply	5		
4.4 Residual Risk	6		
5. Identification and Unpacking	7-8		
5.1 Product Overview	7		
5.2 What's in the Box?	8		
5.3 Packaging	8		
6. Preparation Instructions	9		
6.1 Attaching the Castors	9		
6.2 Fitting the Drain Plug	9		
7. Setting Up the Vacuum Cleaner	10		
7.1 Setting Up	10		
7.2 Dust Clearing Button	10		
8. Operating Instructions	11-12		
8.1 Dry Vacuuming	11		
8.2 Wet Vacuuming	11		
8.3 Blower Function	12		
8.4 Using the Vacuum Cleaner with Power Tool Dust Extraction	12		

# 3. Product Introduction



## 3.1 Intended Use

This vacuum cleaner is designed to pick up both wet and dry material. Ideally suited for use in a workshop or garage environment and for DIY around the home.

Any other application beyond the conditions established for use will be considered misuse. Draper Tools accepts no responsibility for improper use of this product.

Read this manual in full before attempting to assemble, operate or maintain the product, and retain it for later use.

## 3.2 Specification

Stock No.	20529
Part No.	WDV30SSPA
Rated voltage:	230V/50Hz
Rated input:	1600W
Vacuum protection rating:	IPX4
Accessories diameter:	35mm
Maximum vacuum pressure:	18kPa
Maximum air flow:	53L/S
Tank Capacity:	30L
Liquid volume:	18.9L
Dry volume:	21.7L
<b>Power take off socket</b>	
Power take off:	1300W
Protection rating:	IP54
Power cord length (approx.):	5M
<b>Noise emissions:</b>	
Sound pressure level:	85dB (A)
Net weight:	7.33kg

**Important:** Read all the Health and Safety instructions before attempting to operate, maintain or repair this product. Failure to follow these instructions may result in injury or damage to the user or the product.

### 4.1 General Health and Safety Precautions



**WARNING! To reduce the risk of electric shock or injury:**

- **DO NOT** leave the appliance unattended when plugged in or switched on.
- **ALWAYS** switch off and unplug from the power supply when not in use, changing accessories or performing any cleaning or maintenance.
- **DO NOT** use this appliance near flammable liquids, gases or explosive vapours or dust. Sparks inside the motor can ignite flammable vapours or dust.
- **DANGER! DO NOT** vacuum hot or glowing ash, cigarette ends, matches or anything that is burning.
- Keep the cord away from hot surfaces and sharp edges.
- **DO NOT** expose to rain or very damp conditions.
- **DO NOT** pull or carry the appliance by the power cord.
- **DO NOT** pull the plug from the socket by the cord. To unplug grasp by the plug, not the cord.
- **DO NOT** use with a damaged or worn cord, plug or any other parts.
- If the appliance is not working, has been damaged, left outside or dropped in water, get it checked and repaired by a qualified person.
- **DO NOT** run the appliance over the cord.
- **DO NOT** touch the cord or appliance with wet hands.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

### 4.2 Additional Health & Safety Precautions for Vacuum Cleaners

- **DO NOT** modify the appliance and only use for its intended use.
- Wear protective clothing and gloves.
- **DO NOT** allow untrained persons to operate the cleaner.
- To reduce the risk of health hazards from vapours and dust, **DO NOT** vacuum toxic materials.
- **DO NOT** use or store near hazardous materials.
- **DO NOT** use with a damaged filter or without a filter installed.
- **DO NOT** place any objects into the ventilation openings and **DO NOT** use if the ventilation openings are blocked.
- The hose should be checked regularly and must not be used if damaged.
- Unplug before connecting the hose.
- To reduce the risk of falls, take extra care when cleaning stairs.
- Keep hair, loose clothing and fingers away from openings and moving parts.
- Only use and replace with recommended parts and attachments.

**When using as a blower:**

- **DO NOT** point or direct the air hose at bystanders or animals.
- Wear eye protection and a dust mask.
- Keep children and bystanders away from the work area.

### 4.3 Connection to the Power Supply

This appliance is supplied with an approved plug and cord for your safety.

If the power supply cord is damaged, it must be replaced by Draper Tools, an authorised service agent or similarly qualified personnel in order to avoid a hazard.

The damaged or incomplete plug, when cut from the cord, shall be disabled to prevent connection to a live electrical outlet.

This appliance is a Class I† and is designed for connection to a power supply matching that detailed on the rating label and compatible with the plug fitted.

The value of the fuse fitted is marked on the pin face of the plug. Should the fuse need replacing, use a small plain-slot screwdriver to remove the fuse cover. Ensure the substitute is of the correct rating, approved to BS 1363/A and ASTA or BS Kite marked. This should only be performed by suitably qualified personnel.


ASTA 

BSI 

If an extension lead is required, use an approved and compatible lead rated for this appliance.

Follow all the instructions supplied with the extension lead.

**Important:** Always follow the extension lead instructions regarding maximum load while the cable is wound. It is recommended that the power cord and/or the extension lead are fully unwound before connecting to a power supply. A coiled extension lead generates heat which could melt the lead and cause a fire.


†Earthed : This product requires an earth connection to protect against electric shock from accessible conductive parts in the event of a failure of the basic insulation.

It is recommended that this vacuum cleaner is used with a residual current device (RCD).

### 4.4 Residual Risk

The safety instructions in this manual cannot account for all possible conditions and situations that may occur. Exercise common sense and caution when using this product and protect against any additional conceivable risks.

### 5.1 Product Overview




- |  |                          |
|--|--------------------------|
| (1) Drain plug                               | (7) Exhaust port         |
| (2) Stainless steel tank                     | (8) Power head           |
| (3) Vacuum port                              | (9) Dust clearing button |
| (4) Power tool socket                        | (10) Retaining clips     |
| (5) <b>ON/OFF</b> & Power tool socket switch | (11) Cord and plug       |
| (6) Handle clasps                            |                          |

### 5.2 What's in the Box?

Carefully remove the product from the packaging and examine it for any signs of damage that may have occurred during shipment.

Before assembling the product, lay the contents out and check them against the parts shown below. If any part is

damaged or missing, do not attempt to use the product. Please contact the Draper Helpline; contact details can be found at the back of this manual.



- (12) 2M Suction hose
- (13) Telescopic extension tube
- (14) Crevice tool
- (15) Metal floor vacuum head
- (16) Cloth filter
- (17) Foam filter

- (18) Paper dustbag
- (19) Round brush
- (20) 4 X Castors
- (21) Plastic/rubber floor head (wet)
- (22) Adaptor

Please visit **[drapertools.com](http://drapertools.com)** for our full range of accessories and consumables.

### 5.3 Packaging

Keep the product packaging for the duration of the warranty period in case the product needs to be returned for repair.



**WARNING! Keep packaging materials out of reach of children. Dispose of packaging correctly and responsibly and in accordance with local regulations.**



**Important:** Before preparing or adjusting this product, read and understand all the safety instructions listed in this manual. Ensure that the vacuum cleaner is unplugged from the power supply before assembling.

**Note:** Remove all the accessories from inside the tank before fitting the castors and setting up the vacuum cleaner.

### 6.1 Attaching the Castors (Fig.1)

- Remove the power head (8) and turn the tank (2) upside down.
- Then firmly push the four castors (20) into the underside of the tank base. (Fig. 1).




Fig. 1

### 6.2 Fitting the Drain Plug (Fig.2)

- Ensure the drain plug (1) is fitted securely in position before using the vacuum cleaner.



Fig. 2


## 7. Setting Up the Vacuum Cleaner

EN

**Important:** Ensure the vacuum is unplugged from the power socket before assembling.

### 7.1 Setting Up (Fig. 3 & Fig. 6)

1. Release the retaining clips (10) and lift off the power head (8).
2. Fit the required and correct filter.
  - **Cloth filter** (16) and paper dustbag (18) for dry vacuuming (refer to **Section 8.1**). **NOT** suitable for wet vacuuming.
  - **Foam filter** (17) for wet vacuuming only (refer to **Section 8.2**). **NOT** suitable for dry vacuuming.
3. Refit the power head (8) and secure using the two retaining clips (10).
4. Insert the connector end of the hose (12) into the vacuum port (3). Then push in and turn anticlockwise to lock in position.
  - To remove the hose, turn clockwise and pull out.
5. Fit the required attachment to the end of the hose.
6. Connect to the power supply and turn the **ON/OFF** switch (5) to.
  - 'I' position for normal vacuuming.
  - 'II' position for connected power tool operation (refer to **Section 8.4**)

 **WARNING! The power tool socket (4) remains live while the vacuum is plugged into the mains supply.**

### 7.2 Dust Clearing Button (Fig. 7)

- Press the dust clearing button (9) to clear the cloth filter of dust build up. Any dust adhering to the filter is blown and shaken off into the tank.
- To use first block the end of the hose inlet and then press the button and release.




Fig. 3




Fig. 4



Fig. 5

Fig. 6



Fig. 7

**Important:** Before operating this product, read and understand all the safety instructions listed in this manual. Ensure that the product is fully assembled and correctly set up for use.

- **DO NOT** operate the vacuum cleaner without the correct filter fitted.
- Empty the tank before changing between wet and dry vacuuming.

### 8.1 Dry Vacuuming (Fig. 8 & Fig. 9)

1. Ensure the vacuum is unplugged from the power outlet.
2. Fit the cloth filter (16) over the float cage. Ensure that it is pushed down securely and fully covers the float cage.
  - **DO NOT** use the cloth filter for liquid vacuuming.
- **Optional** – for improved filtration, fit a paper dust bag (18) as well as the cloth filter. As suction power decreases, replace the dustbag.




Fig. 8




Fig. 9

### 8.2 Wet Vacuuming (Fig. 10)

1. Ensure the vacuum is unplugged from the power outlet.
2. Remove the dustbag (18) and cloth filter (16) if fitted.
3. Fit the foam filter (17) by carefully sliding the foam sleeve completely over the filter/float cage.

**Important:** – When vacuuming large quantities of liquids use the crevice tool (14), **DO NOT** immerse the tool nozzle completely in the liquid to allow for adequate air flow.

The vacuum is fitted with a float valve that will cause the motor to work harder and become noisier when the maximum liquid level is reached. Empty the tank at this time.

4. After use remove the drain plug (1) and empty the water from the tank.




Fig. 10

### 8.3 Blower Function (Fig. 11)

1. Ensure the vacuum cleaner is switched off and unplugged.
2. Check that the tank is empty before using the blower.
3. Connect the flexible hose (12) to the exhaust port (7),
4. Connect to the power supply and turn the '**ON/OFF**' switch to the '**I**' position.

### 8.4 Using the Vacuum Cleaner with Power Tool Dust Extraction (Fig.11 - Fig.12)

1. Use the adaptor (22) supplied to attach the vacuum hose (12) to the power tool dust extraction port.
  2. Plug the power tool cord into the power tool socket (4).
  3. Turn the **ON/OFF** switch (5) to position '**II**'.
- The vacuum cleaner will start one second after the power tool is switched on.
  - The vacuum cleaner will continue to run for approx five seconds after the power tool is switched off.




Fig. 11



Fig. 12

**Important:** Always unplug from the power supply before carrying out any cleaning, adjustments, servicing or maintenance.

- If the plug or power supply cord is damaged it must, for safety reason be replaced by Draper Tools, an authorised repairer or similarly qualified person in order to avoid a hazard.

9.1 General Maintenance

- Clean and maintain the vacuum cleaner correctly and regularly to ensure optimum performance.
- **DO NOT** use abrasives or solvents to clean this product.
- **Wet Vacuuming** – To prevent the risk of mildew, empty the tank and clean both inside and outside. Remove the foam filter and allow to dry before storage.
- Clean the cloth or foam filter with mild soap and water and rinse well. Dry before refitting.
- The motor must be correctly ventilated during operation, so avoid blocking the air inlets.
- When not in use, store in a safe, dry and childproof location.

9.2 Troubleshooting

Problem	Possible Cause	Remedy
Vacuum cleaner not operating.	No power supply.	Check unit plugged in and power supply is working correctly.
	Faulty power supply.	Unplug and examine power cord. If damaged, contact the Draper Tools helpline for assistance.
	Switch not in the <b>On 'I'</b> or <b>'II'</b> position.	Move switch to correct <b>'ON'</b> position.
	Collection tank full.	Empty the tank.
Dust coming from power head.	Cloth filter is missing or damaged.	Fit or replace cloth filter.
Reduced efficiency and motor noisy or vibrations noted.	Liquid at maximum level in tank.	Empty tank. Clean or replace foam filter.
	Blockage in tool, hose or tank collection inlet.	Unplug vacuum cleaner and check for blockage and clear.
	Cloth filter blocked by fine dust.	Clean or replace filter.

## 10. Spares, Returns and Disposal

EN

For spare parts, servicing, and repair and replacement options, please contact the Draper Tools Product Helpline for details of your nearest authorised agent.

Draper Tools will endeavour to hold any spare parts, if applicable, for seven years from the date that it sells the final matching stock item.

Any servicing or repairs carried out by unauthorised personnel or installation of spare parts not supplied by Draper Tools will invalidate your warranty.

At the end of its working life, dispose of the product responsibly and in line with local regulations. Recycle where possible.

- **DO NOT** dispose of this product with domestic waste; most local authorities provide appropriate recycling facilities.



## 11. Warranty

EN

12 months from date of purchase - Visit **drapertools.com/warranty/** for more information.

However, if the tools are hired out, the warranty period is 90 days from the date of purchase.

**Draper Tools Limited**



Read the instruction manual



Wear face mask and safety glasses



Wear ear defenders



For indoor use only;  
do not expose to rain



WEEE –  
Waste Electrical & Electronic Equipment  
Do not dispose of Waste Electrical & Electronic Equipment  
in with domestic rubbish



Earthed



European conformity



UK Conformity Assessed

## Contact Details

### **Draper Tools**

Draper Tools Limited  
Hursley Road  
Chandler's Ford  
Eastleigh  
Hampshire  
SO53 1YF  
UK

**Website:** [drapertools.com](http://drapertools.com)

**Email:** [sales@drapertools.com](mailto:sales@drapertools.com)

**Product Helpline:** +44 (0) 23 8049 4344

**Telephone Sales Desk:** +44 (0) 23 8049 4333

**General Enquiries:** +44 (0) 23 8026 6355

### **Delta International**

Delta International BV  
Oude Graaf 8  
6002 NL  
Weert  
Netherlands

Please contact the Draper Tools Product Helpline for repair and servicing enquiries.