

**DRAPER**<sup>®</sup>

**STORMFORCE**

**GB** ORIGINAL LANGUAGE

230V

# HEAT GUN

58329 (EU 37643)



**UK**  
**CA** **CE**

**(F)** **PISTOLET  
THERMIQUE DE**

230V  
58329 (EU 37645)

**(E)** **PISTOLA TÉRMICA**

230V  
58329 (EU 37645)

**(P)** **PISTOLA TÉRMICA  
DE**

230V  
58329 (EU 37645)

**(D)** 230V  
**HEIßLUFTPISTOLE**  
58329 (EU 37645)

**(NL)** 230V  
**WARMTEPISTOOL**  
58329 (EU 37645)

# 1. INTRODUCTION



## 1.1 SCOPE

Ideal for paint stripping, thawing pipes and other DIY applications.

Part of Draper Stormforce range, this product is intended for domestic and infrequent light trade use. Any application other than that it was intended for, is considered misuse.

This product is not a toy and must not be used by children or any person with reduced physical, sensory or mental capabilities or lack of experience and knowledge, or people unfamiliar with these instructions.

Local regulations may restrict the age of the operator.

## 1.2 UNDERSTANDING THIS MANUALS SAFETY CONTENT:

**Warning!** – Information that draws attention to the risk of injury or death.

**Caution!** – Information that draws attention to the risk of damage to the product or surroundings.

## 1.3 EXPLANATION OF SYMBOLS



Read the instruction manual.



Wear suitable eye/face protection.



Wear protective gloves.



Keep out of the reach of children.



**Warning!**



Machine weight.



Class II construction  
(Double insulated).



WEEE –  
Waste Electrical & Electronic Equipment.

Do not dispose of Waste Electrical & Electronic Equipment in with domestic rubbish.



UK Conformity Assessed.



European conformity.

# 2. SPECIFICATION



## 2.1 SPECIFICATION

Stock No's. ....	58329, 37645
Part No's. ....	HG1800SF, HG1800SF/EU
Rated voltage .....	230V~50Hz
Rated input .....	1800W
Temperature (approx.)	
Setting 1 .....	400°C
Setting 2 .....	600°C
Air flow volume	
Setting 1 .....	250L/min
Setting 2 .....	500L/min
Weight (machine only).....	0.75kg

# 3. HEALTH AND SAFETY INFORMATION



## 3.1 GENERAL SAFETY INSTRUCTIONS FOR POWER TOOL USE

**Warning! Read all safety warnings, instructions, illustrations and specifications provided with this power tool.** Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

**Save all warnings and instructions for future reference.**

The term “power tools” in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

### 1) Work area safety

- Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

### 2) Electrical safety

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of

electric shock if your body is earthed or grounded.

- c) **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- d) **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
- e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f) **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

### 3) Personal safety

- a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- b) **Use personal protective equipment Always wear eye protection.** Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection use for appropriate conditions will reduce personal injuries.
- c) **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- d) **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- f) **Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
- g) **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
- h) **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** A careless action can cause severe injury within a fraction of a

second.

### 4) Power tool use and care

- a) **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- b) **Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c) **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- e) **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
- f) **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
- h) **Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.


### 5) Service

- a) **Have your power tool serviced by a qualified repair person using only identical replacements parts.** This will ensure that the safety of the power tool is maintained.

## 3.2 SPECIFIC SAFETY INSTRUCTIONS FOR HEAT GUNS

 **Warning!** Danger of explosion!

- This hot air gun can explosively ignite combustible fluids and gases.
- Do not work in a potentially explosive environment. Check the surrounding before starting to work.
- Do not work on fuels or gas containers or in their vicinity, even when they are empty.

 **Warning!** Danger of fire!

- Heat can ignite combustible materials including those that are hidden behind coverings, in ceilings, floors or cavities.
- Inspect the work area before starting work and in case of doubt, abstain from using the hot air tool.
- Do not point the unit at the same spot for extended periods.

## 3.3 RESIDUAL RISK

**Important:** Although the safety instructions and operating manuals for our tools contain extensive instructions of safe working with power tools, every power tool involves a certain residual risk which can not be completely excluded by safety mechanisms. Power tools must therefore always be operated with caution!

## 3.4 CONNECTION TO THE POWER SUPPLY

**Caution:** Risk of electric shock. Do not open.


This appliance is supplied with an approved plug and cable for your safety.

Never use a damaged or incomplete plug.

This appliance is Class II† and is designed for connection to a power supply matching that detailed on the rating label and compatible with the plug fitted.

Carefully select an extension lead. Some machines are not suitable for use with extension leads. If the tool is designed for use outdoors, only use an extension lead suitable for that environment in conjunction with an RCD adaptor. When using an extension lead, select one capable of handling the current (amps) drawn by the machine in use. Ensure the cable is fully unwound regardless of the distance between the power supply and the tool. Excess current (amps) and a coiled extension lead will cause the cable to heat up and can result in fire.

Keep extension leads away from moving hazardous parts to avoid damages to the cable which can lead to contact with live parts. Position cable safely to avoid tripping over.

†Double insulated : This product requires no earth connection as supplementary insulation is applied to the basic insulation to protect against electric shock in the event of failure of the basic insulation.

**Important!** If using an extension lead, follow the instructions that came with your lead regarding maximum load while cable is wound. If in doubt, ensure that the entire cable is unwound. Using a coiled extension lead will generate heat which could melt the lead and cause a fire.

## 4. UNPACKING AND CHECKING



### 4.1 PACKAGING

Carefully remove the product from the packaging and examine it for any sign of damage. Check contents against the parts shown in Fig A. If any part is damaged or missing, please contact the Draper Help Line (see back page). Do not attempt to use the product!

The packaging material should be retained during the warranty period, in case the product needs to be returned for repair.

 **Warning!**

- Some of the packaging materials may be harmful to children. Do not leave any of these materials in reach of children.
- If any of the packaging is to be thrown away, make sure they are disposed of correctly, according to local regulations.

## 5. IDENTIFICATION – FIG.A



FIG.A

**Note:** For details of our full range of accessories and consumables, please visit [drapertools.com](http://drapertools.com)

## 6. BASIC HEAT GUN OPERATIONS

**Note:** Isolate the power source by removing the power supply plug from the socket, before carrying out adjustment, servicing or maintenance.

**Important:** Ensure that the machine is switched OFF before connecting to the power supply.

**Important:** The heating wire element of this heat gun has a protective coating. Please note that due to the vaporization of this coating, some smoke may be generated during the first 20 – 30 seconds of use only.

### 6.1 ON/OFF SWITCH – FIG.1

The ON/OFF switch has three positions/settings:

- Position O is off.
- Position 1 ( I ) is approximately 400°C.
- Position 2 ( II ) is high heat approximately 600°C.



FIG. 1

### 6.2 FREE-STANDING OPERATION – FIG.2

This heat gun can be positioned free-standing. This allows the user to have both hands free which is essential for certain applications, e.g. pipe bending, plastic welding, etc. Position the heat gun on its end,

only on a level suitable surface.

**Note:** Never leave the heat gun unattended or switched on.



FIG. 2

### 6.3 THERMAL OVERLOAD PROTECTION

Please note this machine is fitted with a safety thermal overload protection. If the product, is continuously used too close to the workpiece resulting in over heating and the machine potentially catching fire, the thermal overload protection will be activated and heat production will stop.

**Note:** The fan and motor will continue to run, drawing in cool air past the thermal overload protection device. After a short time (10 seconds) the hot air gun will automatically start producing heat again.

**Warning!** Remember the nozzle will remain hot for sometime – a safe storage location should be used.

Continued thermal overload protection activation may cause permanent damage. If the heat gun becomes too hot as in misuse situations then a permanent fail safe will operate and the heat gun will become inoperable.

## 7. BASIC HEAT GUN OPERATIONS



**Note:** The following instructions should only be used as a guide as the ideal temperature should be ascertained by performing a test on the workpiece.

Heating efficiency will vary depending on the properties of the workpiece, and the distance kept between the metal nozzle and the workpiece itself.

### 7.1 PAINT REMOVAL FROM WINDOW FRAMES – FIG.3

**Important:** Do not direct the hot air gun at the glass during use as it may crack. Always use the glass protection nozzle (7). Do not touch the glass with the hot nozzle.




FIG. 3

### 7.2 HEATING AND SHAPING PLASTIC TUBING – FIG.4

Fit the reflector hook nozzle (9). Switch the hot air gun on to the low heat setting and, carefully heat the tubing evenly moving it from side to side.




FIG. 4

### 7.3 DEFROSTING WATER PIPES – FIG.5

**Important:** Do not defrost plastic tubing/piping. Fit the reflector hook nozzle (9). Switch the hot air gun on to the higher heat setting and, gently heat the frozen area of the pipe starting from the edge of the area and moving in towards the centre.

**Important:** Take care not to heat the pipe too quickly as this could cause the pipe to crack and burst. Do not overheat water pipe joints as these are only soldered together (max. 200°C).






FIG. 5

## 8. MAINTENANCE (GB)

### 8.1 MAINTENANCE

Regular inspection and cleaning reduces the necessity for maintenance operations and will keep your tool in good working condition.

The motor must be correctly ventilated during tool operation. Avoid blocking the air inlets and vacuum the ventilation slots regularly.

## 9. WARRANTY (GB)

### 9.1 WARRANTY

Draper tools have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship.

Should the tool develop a fault, please return the complete tool to your nearest distributor or contact:

Draper Tools Limited, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF, England.

Telephone Sales Desk: +44 (0)23 8049 4333 or:

Product Helpline +44 (0)23 8049 4344.

A proof of purchase must be provided.

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This warranty period covering labour is 12 months from the date of purchase except where tools are hired out when the warranty period is 90 days from the date of purchase. The warranty is extended to 12 months for parts only. This warranty does not apply to any consumable parts, any type of battery or normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted or made by any personnel other than the authorised Draper warranty repair agent.

**Note:** If the tool is found not to be within the terms of warranty, repairs and carriage charges will be quoted and made accordingly.

This warranty applies in lieu of any other warranty expressed or implied and variations of its terms are not

authorised.

Your Draper warranty is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the warranty period.

Please note that this warranty is an additional benefit and does not affect your statutory rights.

**Draper Tools Limited.**

## 10. DISPOSAL (GB)

### 10.1 DISPOSAL

- At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.
- Contact your local authority for details of collection schemes in your area.

In all circumstances:

- Do not dispose of power tools with domestic waste.
- Do not incinerate.
- Do not dispose of WEEE\* as unsorted municipal waste.



\* Waste Electrical & Electronic Equipment.